



The Toolroom Company

ET 16-25 SERIES FRYER 2300 CONTROL

MAINTENANCE MANUAL



TABLE OF CONTENTS

1.0 – SAFETY INFORMATION

General Safety	3
1.01 Mechanical Safety	4
1.02 Electrical Safety	5

2.0 – BASIC INSTALLATION

2.1 WHERE TO PLACE YOUR MACHINE

2.11 Foundation	6
2.12 Environmental Conditions	6

2.2 UNLOADING YOUR MACHINE

2.3 RECEIVING YOUR MACHINE

2.4 UNPACK AND PLACE YOUR MACHINE

2.5 PRIOR TO THE ARRIVAL OF THE TECHNICIAN

2.51 Installation Safety Instructions	7
2.52 Cleaning & Lubricating Machine	7
2.53 Line Voltage Check	7
2.54 Electrical Precautions	8

2.6 LEVELING THE MACHINE

2.61 Leveling Procedure	9
-------------------------------	---

3.0 – GENERAL INFORMATION

3.1 MAINTENANCE SCHEDULE CHART

3.2 MACHINE COMPONENTS

3.21 Axis Lubrication System	11
3.22 Electrical System	11
3.23 Pneumatic System	12
3.24 Spindle	12
3.25 Flood Coolant System	13

3.3 BASIC MACHINE PROCEDURES

3.31 Set Axis Home Position	14
3.32 Check Axis Backlash	15
3.33 Adjusting Backlash Compensation	15
3.34 Spindle Endplay Adjustment	16
3.35 Check Drive Belts	17

4.0 - 2300 CONTROL

4.1 ACCESSING MACHINE PARAMETERS

4.2 ACCESSING THE SOFTWARE VERSION

4.3 REVERT TO THE FACTORY SET PASSWORD

4.4 ADJUSTING INPUT VOLTAGE PARAMETERS

4.5 M-CODES

4.6 ALARMS

4.61 Siemens Alarms	21
4.62 Fryer PLC Alarms and Descriptions	21
4.63 Clearing an Alarm	23

4.7 WORKING WITH FILES

4.71 File Types	23
-----------------------	----

4.72 Back-Up A 2300 Archive File to A USB Stick	23
4.73 Reloading an Archive File	24
4.74 Backing Up Tool Data on the 2300 Control	24
4.8 ADDING A SOFTWARE OPTION TO AN 2300 CONTROL	25
4.9 SET UP NETWORK DRIVE IN AN 2300	27
5.0 – TURRET	
5.1 ALIGNING THE TURRET	29
6.0 – DRAWINGS AND PARTS LIST	
6.1 2300 FRONT CONSOLE LAYOUT & PARTS LIST	30
6.2 2300 CONTROL ELECTRICAL PANEL LAYOUT & PARTS LIST	31
6.3 MAIN MACHINE ASSEMBLY DRAWING	32
6.4 BASE CASTING ASSEMBLY DRAWING.....	35
6.5 ELECTRICAL CABINET DRAWING	37
6.6 HEADSTOCK DRAWING	38
6.7 HEADSTOCK LUBRICATION SYSTEM DRAWING	41
6.8 SADDLE DRAWING #1	43
6.9 SADDLE DRAWING #2	46
6.10 SHEET METAL ASSEMBLY DRAWING	49
6.11 TAIL STOCK ASSEMBLY (END VIEW) DRAWING	50
6.12 TAIL STOCK ASSEMBLY (SIDE VIEW) DRAWING	52

SAFETY INFORMATION- LATHES

READ BEFORE INSTALLING OR OPERATING

***NOTE: THIS MACHINE IS AUTOMATICALLY CONTROLLED
AND MAY START AT ANY TIME.***



All CNC machines contain hazards from rotating parts, belts and pulleys, high voltage electricity, noise, and compressed air. When using CNC machines and their components, basic safety precautions must always be followed to reduce the risk of personal injury and mechanical damage.

It is the machine owner's responsibility to make sure all personnel who are involved in installation and operation of this machine are thoroughly acquainted with the procedures and safety instructions provided herein *BEFORE* they perform any actual work.

Only Fryer factory-trained service personnel should troubleshoot and repair the equipment.

Do not modify or alter this equipment in any way without first consulting Fryer Machine. Any modification or alteration of could lead to personal injury and/or mechanical damage and/or void your warranty.



1. Use the emergency stop button to stop all machine motion in the event of an emergency.
2. Use the feed hold button to stop axis movement during normal operation.
3. Before operating switches, always check that they are the right ones.
4. Do not change parameters, voltages and other electrical settings unless directed by an authorized service technician. If such changes are unavoidable follow the directions provided by the technician carefully.
5. The best defense against injuries on a turning machine is to be alert. Never initiate a machine function unless you completely understand what the function will cause the machine to do.

6. Keep machine and area around it clean and well lighted. Never allow chips, coolant, or oil to remain on the floor. Do not leave loose objects on or around machine.
7. Use appropriate eye and ear protection while operating the machine. ANSI-approved impact safety goggles and OSHA-approved ear protection are recommended to reduce the risks of sight damage and hearing loss.
8. Keep all loose clothing, hair, jewelry away from the machine and from contacting the spindle
9. Gloves are easily caught in moving parts. Take them off before turning on the machine.
10. Always wear safety shoes with steel toes and oil-resistant soles.
11. Do not paint, alter, deface, or remove any warning plates from the machine. Replacement plates are available from Fryer Machine Systems.
12. Keep flammable liquids and materials away from the work area and hot chips.
13. Coolant and oils can make surfaces on the machine slippery. They can also present an electrical hazard if the machine has power on. Therefore, do not stand on any part of the machine at any time.
14. Keep material in the spindle from extending beyond the rear edge of the spindle.
15. Check for damaged parts and tools before operating the machine. Any part of a tool that is damaged should be properly repaired or replaced. Do not operate the machine if any component does not appear to be functioning correctly.
16. Improperly clamped parts machined at high speeds/feeds may be ejected and puncture the safety door. Machining oversized or marginally clamped parts is not safe.
17. To avoid turret damage, ensure that tools are properly aligned when loading tools and that boring bars and facing tools do not protrude behind the back of the faceplate.
18. Windows must be replaced immediately if damaged or severely scratched – contact the factory for replacement panels.
19. Do not attempt to operate the machine before all of the installation instructions have been completed.
20. Be sure to review the Maintenance section of this manual for instructions to keep your machine running properly.

10.1 Mechanical Safety

1. Always press emergency stop when the machine is not in use.
2. Never operate the machine with any cover or shield open or removed.
3. Never reach into the work area when the spindle is turning or if the machine is in automatic mode.
4. Put the machine in manual mode and be sure last programmed function has been completed before reaching inside of the work area.
5. The functions of the machine make it impossible to eliminate all pinch points. Be particularly aware of the following pinch points:
 - a. Spindle and chuck rotation
 - b. Indexing of turret and tools
 - c. Carriage and cross-slide movement
 - d. Tailstock movement, both quill and body
6. Do not operate machine without axis motor covers or axis way covers in place.
7. Report any loose, worn, or broken parts to your supervisor. The same action should be taken if any unusual noise or machine action occurs.

8. The electric components are protected from normal moisture resulting from humidity, use of water base soluble, such as coolant, etc. **DO NOT**, however, use water hose to clean the machine or the area around it.
9. Never touch a machine control device or electrical component when your hand is wet.
10. Never clean up chips while the machine is running or is in automatic mode.
11. Do not manually deburr workpieces being rotated under power.
12. At the end of the workday the machine should be placed in "EMERGENCY STOP MODE"
13. When restarting a machine after it has been shut down always assume it has been altered. Recheck all phases of the job as though you were running the first piece.
14. Never touch spindle start or spindle jog control until hands, feet, and body are well clear of the work area.
15. Never extend an unsupported bar out of the rear of the spindle or hydraulic cylinder. Doing so can cause the bar to bend or break resulting in damage or injury.
16. If your turning machine has a bar feeder interfaced to it keep yourself and others away from the exit end of the bar feeder when the machine is running.

1.02 Electrical Safety

1. **WARNING:** Electrical enclosures contain high voltage. Disconnect equipment from power source before opening cabinets.
2. Before replacing a fuse, switch off the machine.
3. **Immediately turn off power if:**
 - Power problems develop
 - In the event of electrical storms.
 - Ambient temperatures exceed 105 degrees Fahrenheit (40 degrees C)
4. The electrical power must meet the specifications in this manual. Attempting to run the machine from any other source can cause severe damage and will void the warranty.
5. The electrical panel should be closed and locked at all times except during service
6. When the main circuit breaker is on, there is high voltage throughout the electrical panel and some components operate at high temperatures. Therefore, extreme caution is required.
7. Do not reset a circuit breaker until the reason for the fault is investigated.
8. Never service the machine with the power connected.

2.0 BASIC INSTALLATION

2.1 WHERE TO PLACE YOUR MACHINE

Thank you for choosing Fryer Machine Systems. You have purchased a high quality, custom crafted machine tool designed and built to provide years of trouble-free service. To ensure that your machine is properly installed we ask that you review the following information prior to the shipment of your machine.

2.11 Foundation

Your foundation must be a minimum 6" (150mm) thick concrete slab floor and should be placed on a single slab with no seams. Be sure to leave space around the machine for leveling components and access to the electrical cabinet.

If your floor does not meet these specifications, contact the factory for further recommendations.

Install the machine on the first or second floor. Take the stress of ceiling and foundation into careful consideration to ensure that the machine load can be offset.

2.12 Environmental Conditions

Generally, the machine will be installed in the following conditions. However, these may change over a period of time or in response to seasonal changes.

- Supply voltage: +/- 10% of voltage listed on serial number tag.
- Source frequency: ± 2 Hz of frequency listed on serial number tag
- Temperature effects dimensional accuracy, therefore, ambient temperatures should not exceed 105 degrees Fahrenheit. Also avoid exposing the machine to direct sunlight or heat rays which can change the environmental temperature.
- Relative Humidity: Less than 80% (Temperature changes should not cause condensation)
- Atmosphere: Free from excessive dust, fumes, corrosive gases, and salt
- Avoid exposing the machine to abnormal vibration.

2.2 UNLOADING YOUR MACHINE

Fryer machines are shipped on skids designed for forklift offloading. Be sure your forklift is rated for the proper weight of the machine.

Note: If you are using a crane for offloading, please contact the factory in advance for instructions as damage can occur if supported in the wrong locations.

2.3 RECEIVING YOUR MACHINE

NOTE: If you have a door that is less than 8' wide x 10' high, please contact the factory prior to shipment so that we can make sure your machine is packaged to fit into your door openings.

1. Fryer machines are carefully packed to avoid damage in transit; however, we ask that you **UNWRAP AND INSPECT YOUR MACHINE AS THOROUGHLY AS POSSIBLE PRIOR TO SIGNING THE BILL OF LADING.** If a digital camera is available, pictures should be taken before the machine is moved further. Pictures should be sent to service@fryermachine.com.
2. Place the machine in its location and complete inspection. If there is any damage to your machine, Fryer should be notified immediately. This will enable us to provide replacement parts before the service technician arrives install the machine.
3. If you have any questions about any of these installation instructions or other questions about your new Fryer Machine Systems machine, please call the Fryer Service Department and one of our trained technical staff will be happy to assist you.

2.4 UNPACK AND PLACE YOUR MACHINE

To make certain that your machine installation goes smoothly, it is important that the following items are completed **prior** to the arrival of the Fryer authorized service technician. This will ensure that our technician is able to provide you with the maximum amount of training during his allocated time with you.

1. Have your rigger move the machine to the operating location, remove it from the skid and install on ALL leveling pads.
2. Remove all packaging material and thoroughly clean the machine and inspect for hidden damage.
3. Remove all large assemblies from skids and stage next to machine to facilitate ease of assembly.
4. Install leveling pads and level machine. Level with a precision level, using the leveling screws and pads provided with the machine.

2.5 PRIOR TO THE ARRIVAL OF THE TECHNICIAN

2.51 Installation Safety Instructions

Initial start-up of the machine must be performed by a Fryer Machine Systems authorized service technician.

2.52 Cleaning & Lubricating Machine

All protective coatings (cosmoline) must be removed before using the machine.

Be cautious when selecting a suitable cleaning agent. Paraffin applied with a clean brush will soften the protective coating. The protective coating can then be removed with clean rags.

- WD-40 or a similar product is recommended for cleaning the machine. Do not use gasoline or any other flammable solution to clean the machine.
- Clean all exposed ways of the bed and saddle.

2.53 Line Voltage Check

Line voltage must be $\pm 10\%$ of the voltage listed on the serial number tag.

**INITIAL POWER-UP SHOULD ONLY BE PERFORMED BY
A FRYER TECHNICIAN OR FACTORY AUTHORIZED
REPRESENTATIVE.**

2.54 Electrical Precautions

Wiring

1. Ensure that all local electrical codes are met.
2. Do not connect to the power distribution panel any power cables for devices that can cause line noise, such as welders and high frequency quenching machines.

Grounding

You should always refer to your local electrical code to be sure you are grounding to code. Generally, use a grounding wire with a cross section of more than 14 mm and a resistance to ground of less than 100 ohms. This wire size should be greater than AWG (American Wire Gauge) No. 5 and SWG (British Legal Standard Wire Gauge) No.6.

Generally, the machine should be grounded to a separate grounding rod. If an independent ground cannot be provided for the machine, prepare the ground connection as follows:

1. Connect a single conductor to its own grounding terminal. This will avoid possible serious accidents resulting from ground currents that might otherwise flow in the NC machine if a peripheral device should malfunction.
2. Be careful when using concrete reinforcing rods as grounding points. These reinforcing rods often are used to ground equipment because they usually offer a resistance to ground of less than 100 ohms. In doing so, make the connection as follows: (This also applies to connecting ground wires to regular grounding terminals)
3. Do not use the same grounding reinforcing rod or grounding terminal for other devices since this could lead to line noise such as produced electric welders and high frequency quenching machines.
4. Use a grounding terminal with an adequate electrical performance rating and which is durable.
5. A separate grounding wire should be used, one whose length is as short as possible.
6. Check the resistance to ground by actual measurement.
7. This should measure less than 100 ohms if the single device is connected to its own grounding rod.

Desirable Independent Grounding: Earth resistance: Less than 100 ohms **Common Grounds:**

Resistance to ground = $100 / \text{the number of devices connected to the grounding } (\Omega)$

NEVER GROUND EQUIPMENT IN SERIES!

Connection of Power Line

<p>NOTE: Electrical installation should only be completed by a qualified electrician.</p>
--


1. Make sure that the incoming power is compatible with the requirements of the machine tool (voltage, amperage, phasing). All this information can be found on the machine's serial number tag.
2. Power wires, grounding and over-voltage protection should comply with the local electrical code.
3. **DO NOT** connect if the incoming power is different from the power requirements of the machine. Contact a qualified electrician.

2.6 LEVELING THE MACHINE


Before attempting to use the machine, it will be necessary to accurately level it.

1. Screw the leveling bolts (with nut) into the holes in the base of the machine. Set a leveling pad under.
2. Please prepare the following tools to adjust machine level:
3. Two spirit levels (0.0005"/ft. or 0.013mm/1000mm accuracy)
4. Two adjustable wrenches
5. Clean the bed way and cross slide surfaces thoroughly and set one of the spirit levels on the flat bed way in the longitudinal direction, and the other on the cross slide, perpendicular to the first (if there is only one level available, then use it on both directions alternately).
6. Adjust the six leveling bolts located the bottom of the machine base until the machine is leveled to within 0.001"/ft. (0.08mm/1000mm) in both directions.
7. Lock the nuts on the leveling bolts, and re-check to see whether the level of machine is still correct. Repeat as necessary until machine level is obtained with leveling bolts locked.

After initial installation, check the level once a week for the first month, then check monthly thereafter



X-AXIS



Z-AXIS

3.0 GENERAL INFORMATION

3.1 Maintenance Schedule

CAUTION: Always turn the machine off before performing maintenance.

MAINTENANCE ITEM	RECOMMENDED	Daily	Weekly	As Req'd.	6 Mo	Yearly
Check pressure gages for proper readings	90-125 PSI	X				
Check that machine components and sliding parts have proper lubrication		X				
Check condition of covers for damage or excessive gasket wear		X				
At the end of the day, remove and dispose of chips	Use of brush or vacuum is recommended. Do not use air as it can push chips into ways and ballscrews.	X				
Drain air/water separation			X			
Check wipers for damage			X			
Check coolant level			X			
Check headstock oil level			X			
Check turret oil level (if option is installed)	Mobilub HD Plus 80W90 or equivalent oil		X			
Change coolant	Blasocut BC-40 NF-PL or Equivalent oil			X		
Fill lube pump	Mobil Vactra No. 2, Amoco Waytac No. 68 or Equivalent			X		
Fill air regulator oil for auto shift	Mobil Almo Break-Free Synthetic Air Tool oil (5W-10W) or Equivalent			X		
Check servo cabinet & console fans, clean filters	Frequency should be determined by type of material being cut and number of hours the machine is running.			X		
Check machine level					X	
Check ball screw endplay					X	
Check gibs					X	
Check backlash					X	
Check belt / coupling tension						X
Replace servo cabinet and console filters	Purolator A23465					X
Change headstock (spindle) oil	Mobil DTE ISO VG-32 Hydraulic Oil or Equivalent Oil (VG-22 for ET-18 model)					X
Change hydraulic system oil (if option is installed)	Mobil DTE ISO VG-32 Hydraulic Oil or Equivalent Oil					X
Change turret oil (if option is installed)	Mobilub HD Plus 80W90 or Equivalent oil					X

3.2 MACHINE COMPONENTS

3.21 Axis Lubrication System

- The automatic way lube system is controlled by the PLC in the control. The system only pumps way oil



when the spindle and axes are moving. If there is no machine movement the pump will not pump unnecessary oil. This method greatly reduces way lube usage and keeps oil out of the machine coolant sump and prevents fouling.

- If the machine has been unused for more than 48 hours press the blue pushbutton on the side of the lube tank for approximately 30 seconds to pump oil to the ways. The pressure gage on the tank will indicate if it is working properly.
- If the system detects low way lube it will display the following message in the control: 700040 - WAY OILER PRESSURE FAULT

3.22 Electrical System

- Schematics (1) – The Electrical and Pneumatic Schematics are inside electrical cabinet
- Cabinet Filter Type (2) – Purolator A23465 or equivalent
- Check Filter Interval - Weekly
- Change Filter Interval – As Required (depending on environment)



3.23 Pneumatic System

- Schematic – See Pneumatic Schematic in electrical cabinet (see previous page)



- Pneumatic List / Pressure Settings
 - Main Supply – 90-125 PSI at 5 CFM
 - Air Gun
- Lubrication Requirements – Mobil Almo break free synthetic air tool oil 5W-10W or equivalent
- Check Lubrication Interval – Weekly – Add as needed

3.24 Spindle / Gearbox

Thermal expansion of the machine components can jeopardize machining accuracy. To prevent this condition always warm the machine up.

SPINDLE WARM UP – Warm up the machine by running it for 10 to 20 minutes at about half or one-third the maximum speed in the automatic operation mode.

This automatic operation program should cause each machine component to operate allowing you to check their operation.

SPINDLE DUTY RATING – Follow the duty rating outlined below

- If it is required for the spindle to run continuously (24 hours a day), the spindle must not run above 80% of the maximum RPM.
- If it is required for the spindle to run at maximum RPM, the spindle must not run more than 2 hours straight. After 2 hours of run time at maximum RPM, the spindle must be slowed down to 50% of the maximum RPM for at least 30 minutes before running at the maximum RPM again.

3.25 Flood Coolant System

The flood coolant system consists of a submersible flood pump mounted in the base casting of the machine. The flood line runs up the back of the column and through the Z-axis cable track. It splits at a y-fitting in the headstock where it runs to two separate lengths of loc-line.

- The submersible flood pump is mounted behind the access panel shown below.
- The sump can be drained for coolant changes by using a wet vaccum.





3.3 MACHINE PROCEDURES

3.31 Set Axes Home Positions

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY

The 2300 control comes standard with absolute encoders which generally do not require homing. However, if you have an issue with the battery or the machine is not turned on for an extended length of time the machine may need to be re-homed according to the following procedure. In addition, if an axis motor is removed or there is an issue with a motor coupling or pulley / belt assembly, one or more axes may need to be re-homed.


- Refer to Section 4.1 for directions to access parameter screens.

1. Press 
2. Select **SETUP**
3. Select **MACHINE DATA**
4. Select **AXIS MD**
5. Select **SEARCH**
6. Enter **34210 [0]** in the search field (This will read **ENC_REFP_STATE**)
7. Select **OK**
8. Select the proper axis with the **AXIS + AND AXIS -**
9. Change the parameter **34210 [0]** to **0** for an axis with a motor encoder
10. Change the parameters **34210 [0]** and **34210 [1]** to **0** for an axis with a scale
11. Press **INPUT**
12. Cycle power to machine leaving it off for a minimum of 30 seconds
13. **Take extreme caution now as the machine can be crashed!**
14. Line up the home markers for all axes that need to be homed
15. Press the **E-STOP** button to turn off the servos
16. Press 
17. Select **SETUP**
18. Select **MACHINE DATA**
19. Select **AXIS MD**
20. Select **SEARCH**
21. Enter **34210 [0]** in the search field (This will read **ENC_REFP_STATE**)
22. Select **OK**
23. Select the proper axis with the **AXIS + AND AXIS -**
24. Make sure Parameter **34210 [0]** and **34210 [1]** (if axis has a scale) **are set to 0**. If it is not, it is probable that the wrong axis is selected.
25. Change the parameter **34210 [0]** to **1** for an axis with a motor encoder
26. Change the parameters **34210 [0]** and **34210 [1]** to **1** for an axis with a scale
27. Press **INPUT**
28. Turn the feed rate override all the way down
29. Pull the **E-Stop** button out
30. Select **RESET**
31. Press **HOME RETURN** (should say Jog Ref at the top of the screen)
32. For a mill, press **AXIS+** (refers to the hard key on the manual panel you have selected)
33. When done make sure parameter **34210 [0]** shows **2** for all axes (axis with motor encoder)
34. When done make sure parameter **34210 [0]** and parameter **34210 [1]** shows **2** for all axes (axis with scale)

3.32 Check Axis Backlash

Tools Required: 0.0001" resolution dial indicator, control handwheels handwheel

- Set the indicator along the axis which is being measured. The needle should be in contact with a flat machined surface and the base on a stable, fixed point. See the pictures below which illustrate the setup for the X and Z axes.
- Using the remote handwheel, move the axis in one direction either positive or negative until the indicator is loaded by 0.002".
- Zero the indicator.
- Move the axis in the same direction by 0.005".
- Reverse the direction of the axis by 0.005".
- The additional amount that is needed to reach zero after the 0.005" reverse in direction is the backlash measured.
- This shows the loss of motion in the axis from the ballscrew and linear guide rails. Backlash compensation can be adjusted according to the procedure outlined below in *Section 3.33*.



X-AXIS




Z-AXIS

3.33 Adjusting Backlash Compensation

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY


Refer to Section 4.1 for directions to access parameter screens.

- Press 
- Select **SETUP**
- Select **MACHINE DATA**
- Select **AXIS MD**
- Using **AXIS+ AND AXIS-**, select the correct axis
- Select **SEARCH**
- Enter **32450 [0] or 32450 [1]** if the machine is equipped with glass scales on the selected axis
- Adjust the backlash on each axis
- Select **SET MD ACTIVE (cf)**
- Select **RESET (po)** to reboot the control


3.34 Spindle Endplay Adjustment

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY

1. Remove headstock sheet metal and lid. With the auto-shift air pressure off, set the gearbox in neutral by rotating the shifter shaft manually.



2. Mark the spanner rings with a white line to indicate the original position on the shaft. Loosen set screws on the thrust spanner ring.



Encoder Drive Gear

Thrust Spanner

3. Using an aluminum or brass drift, tighten the spanner ring a $\frac{1}{4}$ " of movement at a time from the white mark. Rotate the spindle by hand and note how easy it is to move. Check the endplay by placing a long shaft in the chuck or spindle bore.

4. Put in neutral, feel the spindle movement, tighten until you feel some resistance then back up slightly.
5. Place the indicator on the side of the spindle nose. Measuring the endplay by checking the side load on the *tapered roller bearings* is more accurate than trying to get and axial movement. Pull and push and note the indicator. Normal endplay is MAX .0002". The spindle will have slight drag when adjusted right. If you hear a rattle, like loose roller cages, it is most likely too loose. While in neutral, manually spin the spindle, it if freewheels, then the thrust is most likely loose. Run it, let it warm up and cool down, readjust and check the endplay. Repeat several times until it is certain that the bearings are seated properly.
6. Replace all sheet metal.

3.35 Check Spindle Motor Belts

- The axis motors are connected to the ballscrews via pulley driven belts. Belts should be checked for excessive wear and proper tension at least every 6 months.
- Once you have gained access to the belts, inspect them for any visible signs or wear or damage. Once the belts are considered acceptable, check each belt for proper tension.
- Belt tension is adjusted by loosening the slotted motor plate and sliding the motor-plate assembly to tighten or loosen the belt as required. Double check all hardware is properly tightened once the belt tension is correct.
- After the inspection is complete and any adjustments made, re-install the belt covers.



4.0 2300 CONTROL

4.1 ACCESSING MACHINE PARAMETERS


PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY

WARNING

Malfunctions of the machine as a result of incorrect or changed parameter settings


As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death.

- Protect the parameterization (parameter assignments) against unauthorized access.
- Handle possible malfunctions by taking suitable measures, e.g. emergency stop or emergency off.

1. Press 
2. Select **SETUP**
3. Select **MACHINE DATA**
4. Available folders: **GENERAL MD / CHANNEL MD / AXIS MD**


4.2 ACCESSING THE SOFTWARE VERSION

To find out the version of the software you are running on your 2300 control:

1. Press 
2. Select **DIAGNOSIS**
3. Select **VERSION**
4. The Software Version number is on the first line and will read: **"V##.## + SP ## + HF ##"**

4.3 REVERT TO THE FACTORY SET PASSWORD

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY

1. Press 
2. Select **SETUP**
3. Select **SET PASSWORD**
4. Enter the password: **SUNRISE**
5. Press **OK**
6. The lower part of the screen should now read "Current Access Level: Manufacturer"

4.4 ADJUSTING INPUT VOLTAGE PARAMETERS

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY

The Siemens control will shut itself off if the line voltage is more than 10% different than the voltage set in the control. You must adjust the parameter to match your line voltage to the machine.

The following alarms may occur when this happens:

1. Power 1 overvoltage
2. Axis drive faults
3. DC link voltage overvoltage

The first step to accurately measure your line voltage. There are two ways to do this.

- Measure the incoming line voltage across all three legs with a voltmeter. Average your readings and write down the value.

OR

- Read the line voltage from the control, follow the following steps:

- Press 

- **SETUP** key

- **INFEED PARAMETER** key

- Find **r25[0]** = and write down the voltage value in this parameter.

- Now you have the proper line voltage value to enter in the control.

Follow the steps below:

- Press E-stop

- Press 


- **SETUP** key

- Press \wedge (up arrow hard key next to machine hard key)

- **DRIVE SYSTEM** key

- **SUPPLY** key

- **POWER DATA** key See screen below:



Wrench icon JOG 3000 Emergency stop

... \Infeeds \Configuration-Power data SLM_3.3:2

☐ Line/DC link identification on first Power ON
(The determined values are saved powerfail-proof.)

Notice:
If the DC link capacity of the drive group is subsequently modified (devices removed/added), a new identification will have to be performed.

Device supply voltage: 480 V
Line rated frequency: 50-60 Hz
OFF3 for axes with voltage dip after: 10 ms

Note:
With a device supply voltage of over 415V, the Active Line Module is operated as open-loop control supply/feedback.

Cancel Accept

- Scroll down to the **Device Supply Voltage** field like in the screen shot above. Enter the line voltage value you obtained in the previous steps, press enter
- Press **ACCEPT** key
- There will be a message that states, “Confirm You Want to Change the Parameter”, Press **YES** key to accept the change.

4.5 M-CODES

An M code in CNC programming controls miscellaneous machine functions, including starting and stopping specific actions or programs.

M00	Program stop
M01	Optional program stop(button on panel must be on
M02	End of Program
M03	Spindle clockwise
M04	Spindle counterclockwise
M05	Spindle stop
M07	Spray mist / air blast
M08	Flood coolant
M09	Coolant off (M07 and M08)
M11	Miscellaneous M-code function on
M12	Miscellaneous M-code function off
M13	Live tool spindle clockwise
M14	Live tool spindle counterclockwise
M15	Live tool spindle off
M17	Reference turret to tool #1
M19	Main spindle orient
M20	Main spindle collet or chuck open (with ID-OD grip switch in OD)
M21	Main spindle collet or chuck close (with ID-OD grip switch in OD)
M22	Tailstock chuck
M23	Tailstock chuck open
M24	Steady rest close
M25	Steady rest open
M26	Tailstock extend (toward Headstock)
M27	Tailstock retract
M29	Rigid Tapping with Live Tools
M30	End of program
M90	Parts catcher catch position
M91	Parts catcher retract stand by position
M33	C axis Brake On
M34	C axis Brake Off
M46	Barfeed cycle-edit barfeed program for alterations
M70	C axis Mode Enable
SPOS=0	C axis Home


NOTE: M-codes may change depending on options the machine is equipped with

4.6 ALARMS

An alarm will be displayed once a fault occurs.

! Warning: *If you do not heed an alarm that is issued and do not resolve the cause of the alarm, it can present a hazard to the machine, the work piece, the saved settings, and in certain circumstances, may cause injury.*

4.61 Siemens Alarms

1. If a familiar alarm number / description appears carefully check the machine and resolve the cause of the alarm.
2. If you are unfamiliar with the alarm in question, proceed to the alarm list as follows:
 - a. Press 
 - b. Select **DIAGNOSTICS**
 - c. Select **ALARM LIST**
3. *Once "**ALARM LIST**" has been selected, press **HELP** key and additional information will be provided on the control screen.

4.62 Fryer PLC Alarms and Descriptions

There are certain PLC alarms in the 700000 range which are not in the **HELP** screen. These are FRYER Machine specific alarms that are for optional equipment installed on the machine. The alarms are listed below:

- 700000 HEADSTOCK OIL PRESSURE FAULT
- 700001 LOW WAY LUBE
- 700002 TURRET THERMAL OVERLOAD
- 700004 GEARSHIFT FAULT-CHECK AIR PRESSURE
- 700005 LOW AIR PRESSURE FAULT
- 700006 LOW HYDRAULIC PRESSURE FAULT
- 700007 C AXIS HANDWHEEL ACTIVE (X AXIS OFF)
- 700008 LIVE TOOL DRIVE GEAR NOT ENGAGED!!
- 700009 CHUCK OR COLLET MUST BE CLOSED TO RUN SPINDLE
- 700010 HIGH PRESSURE COOLANT ALARM
- 700012 TURRET NOT INDEXED OR CLAMPED!
- 700013 TAILSTOCK NOT CLAMPED!
- 700014 SPINDLE OUT OF GEAR
- 700015 TAILSTOCK DRAG ARM NOT AT REST POSITION!
- 700016 WAY OIL PRESSURE SWITCH
- 700032 CONTOUR HANDWHEEL ACTIVE
- 700033 DEPRESS HOLD THEN STOP TO STOP SPINDLE DURING AUTO CYCLE
- 700034 TAILSTOCK NOT CLAMPED
- 700035 REFERENCE RETURN: PRESS START
- 700037 DOOR IS OPEN CLOSE DOOR AND PRESS CYCLE START
- 700038 TOOL SETTER ACTIVE
- 700039 PART PROBE ACTIVE
- 700042 TURRET NOT FULLY CLAMPED

4.63 Clearing an Alarm

1. Carefully check the machine according to the description given in the alarm. Clarification of the alarm codes can be found by using the **HELP** as described above.
2. Resolve the cause of the alarm.
3. Press **RESET**
4. Certain alarms will require a reboot of the control to clear.

4.7 WORKING WITH FILES

4.71 File Types


- **NC** archive contains the machine **PARAMETERS**
- **PLC** archive contains the **LADDER LOGIC** for the machine functions
- **DRV** archive contains the **AXIS DRIVE SETTINGS**

4.72 Back-Up An 2300 Archive File to A USB Stick

- For a download of the machine archive to a USB , press these three keys at the same time on the control:
CTRL + ALT + S
 - This will create a complete standard Easy Archive (**.ARD**) on a **USB**.
-

If a specific file or additional files need to be backed up to a **USB**, do the following:

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY


1. Select the .
2. Select the **STARTUP**.
3. Press the **SYSTEM DATA** key. The data tree will open.
 - i. In the data tree, select the required files from which you want to generate an archive.
4. Press the **ARCHIVE** and **GENERATE ARCHIVE** keys.
5. The **GENERATE ARCHIVE: SELECT STORAGE LOCATION** window opens. Select the **USB** location for archiving.
6. Save the file as serial number of machine and the file name (i.e., for drive archive: "25123DRV")
7. Enter a name and press the **OK** key. The directory is created below the selected folder.
8. Press the **OK** key.
9. Select the format archive **ARD** for 2300, enter the desired name and press the **OK** key to archive the file/files.
 - a. A message informs you if archiving was successful.
10. Press the **OK** key to confirm.
11. An archive file in the **.ARD** (2300) format type is created in the selected directory.

*Note: When backing up an entire machine you should generate an individual file for NC, PLC, Drive, and HMI. When that step is completed, you should generate an archive for all these together.

4.73 Reloading an Archive File

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY

NOTE: Set the password protection to “Current Access Level: Manufacturer”. Refer to Section 4.3 above.


1. Select the  key.
2. Press the **ARCHIVE** and **READ IN ARCHIVE** keys.
3. Select the archive storage location (i.e., **USB**) and position the cursor on the required archive.
4. Note: When the option is not set, the folder for user archives is only displayed if the folder contains at least one archive.
- OR
5. Press the **SEARCH** key and in the search dialog, enter the name of the archive file with file extension **ARD** if you wish to search for a specific archive and press the **OK** key.
6. Press the **OK** or **OVERWRITE ALL** key to overwrite existing files.
- OR
7. Press the **DO NOT OVERWRITE** key if you do not want to overwrite already existing files.
- OR
8. Press the **SKIP** key if the read-in operation is to be continued with the next file.
9. The **READ IN ARCHIVE** window opens and a progress message box appears for the read-in process.
10. You will then obtain a **READ ERROR LOG FOR ARCHIVE** in which the skipped or overwritten files are listed.
11. Press the **CANCEL** key to cancel the read-in process.

*Note: You may only archive one file at a time.

4.74 Backing Up Tool Data on the 2300 Control

Note: Setup data from part programs can only be backed up if they have been saved in the **WORKPIECES** directory.


For part programs, which are located in the **PART PROGRAMS** directory, **SAVE SETUP DATA** is not listed.

1. Select the  operating area.
2. Position the cursor on the program whose tool and zero-point data you wish to back up.
3. Press the **>>** and **ARCHIVE** keys.
4. Press the **SETUP DATA** key.
5. The **BACKUP SETUP DATA** window opens. Select the data you want to back up.
6. Change the specified name of the originally selected program in the **FILE NAME** field, if needed.
7. Press the **OK** key.
8. The setup data will be set up in the same directory in which the selected program is stored as an INI file.

4.8 ADDING A SOFTWARE OPTION ON THE 2300 CONTROL

When you receive your machine all license numbers applicable to your order are activated prior to the machine leaving the factory. If you purchase a control option after the machine arrives at your facility you will receive a license number to active on your control. The license will either require you to go online and create a new license key, or this will be already done for you. If you receive a license certificate like pictured in figure one go to step 1, if not and you already have a license (see figure 2) then proceed to step 8 .

1. You need to obtain the hardware serial # (this not the same as the control serial number) follow these steps:


- Press 
- Press **SETUP**
- Select **LICENSE** (you may have to press the ^ or > key to see the soft key)
- Record the **CF CARD SERIAL #**

This number can also be found in the CF card located in your electrical cabinet. The number on the card is labeled as CFC SN. **CAUTION:** Machine must be powered down before the card is removed.


2. Once you have obtained your Control Hardware Serial Number you are ready to activate your new license number. Using the internet, log onto: www.Siemens.com/Automation/License
 - Click on the link for **DIRECT ACCESS**
 - Enter the **LICENSE # AND DISPATCH NOTE #** from the paperwork into the areas indicated on the web page.



3. Click **NEXT**
4. On the next screen enter your hardware serial number.
5. Next select the control model. Your machine has a 2300.
6. The system will now return a software license key
7. Download PDF and save for your records. Also print the PDF so you can refer to it at the machine to type in new license key.
8. Already have printed license see below:




9. Follow step 1 to get to the license screen. Type in (overwriting old license key) current license key and press input. The field is highlighted, make sure to enter correctly.



10. Press all options soft key

11. Search for the particular option you want to activate. Set the box with the select key. See figure 4.



12. Press back soft key and power machine down. When you turn the machine back on the option should be activated.

4.9 SET UP THE NETWORK DRIVE IN AN 2300


! NOTE: *It is recommended that this procedure be performed by an experienced network administrator.*

The transfer of programs can be achieved by mapping a soft- key to a networked computer. The soft key will appear in the Program Manager screen of the controller.



The computer connected to the network must be configured with a unique username and password. This information will be required for inputting on the controller. A dedicated shared folder is required on the PC for the storage of files.

- Refer to Section 4.1 for directions to access parameter screens.

1. Press 
2. Select **SETUP**
3. Select **START-UP**



4. Press the **HMI** and **LOG. DRIVE** keys. The **SET UP DRIVES** window opens.
5. Select the open key that you want to configure (**example #5**).
6. To allow entry fields to be edited, press the **CHANGE** key.
7. Select the data for the corresponding drive or enter the necessary data.




8. Press the **OK** key. The entries are checked. A window with the appropriate message opens if the data is incomplete or incorrect. Acknowledge the message with **OK** key. If you press the **CANCEL** key, then all of the data that has not been activated is rejected.
9. Restart the control in order to activate the configuration and to obtain the keys in the **PROGRAM MANAGER** screen.




5.0 TURRET

5.1 ALIGNING THE TURRET


1. Dial in the riser block perpendicular in relation to X and Z axis



2. Dial in the turret so the face is parallel to X axis. .0002" over 2"
3. The 8 bolts on the turret faceplate loosen it, and it rotates around the ground center puck
4. Dial in the flatness of the tool mount $\pm .0001$ "- loosen 8 center bolts to rotate



5. Once the turret face plate is parallel to the X axis and the tool mount position is flat to the X axis travel, you can dial in one of the boring holders.



6. Attach indicator to chuck or spindle, place the needle inside the boring holder, and adjust X axis so it is in center of spindle. Set RPM to 10 and use a mirror to check the indicator.
7. Once front to back is even, 0 to 0, any difference top to bottom will have to be compensated by adjusting turret height.
8. If there is any difference in height, shim between the turret and riser block, or grind top of riser.


6.0 – DRAWINGS AND PARTS LIST PARTS

6.1 2300 FRONT CONSOLE & PARTS LIST




REF	PART NO.	DESCRIPTION	QTY
1		Siemens Monitor NCU	1
2		Siemens Control Panel	1
3	DCL-6052	Apron Panel Decal	1
4	HDL-6094	Handwheel for ET-18/21/25 X & Z	2
5	MSM-8210	Keys (3)	1 set
6	SWT-5052	Joystick Switch	1
7	70131528	Fine / Coarse Toggle Switch	1
8	SWT-6210	e-Stop w/ Contact Block	1

6.2 2300 CONTROL ELECTRICAL PANEL LAYOUT & PARTS LIST



2300 CONTROL ELECTRICAL PANEL – PARTS

REF	PART NO.	DESCRIPTION	PARTS NAME	QTY
1		Siemens Touch Screen Filter		1
2		Siemens Servo		1
3		Spindle Module		1
4		Line Module		1
5		NCU		1
6	CMB-3112	PP72/48 I/O Board		1
7		Siemens Reader		1
8	MSE-1330	Wiedmuller Breakout Board		1
9	MSE-6624	Schneider Contactor Relay		1
10		Fuses		1
11	MSE-1610	.75 Kw Transformer		1
12		Fuse, Main		1
13		MCI		1
14	MSE-2940	24V Power Supply		1
15	MSE-6620	Schneider Contactor		1




Main Casting Assembly

MAIN MACHINE ASSEMBLY PARTS LIST

REF	PART NO.	DESCRIPTION	PARTS NAME	Q'TY
1	18-20002	BASE		1
2		SPRING WASHER	M6	4
3		SCREW	M6 x P1.0 x 12	4
4		DIRECT DRIVE PUMP	AM-5	1
5		SERVO MOTOR		1
6	18-20001	BED		1
7		SCREW	M6 x P1.0 x 20L	4
8		SPRING WASHER	M6	4
9		SCREW	M8 x P1.25 x 25L	4
10		SPRING WASHER	M8	4
11	18-20005	MOTOR BASE		1
12		SCREW	M6 x P1.0 x 12L	4
13	18-20004	CLUTCH		1
14	18-20003	BRACKET		1
15		TAPER PIN	#6 x 45L	2
16		SET SCREW	M6 x P1.0 x 6L	2
17		NUT	YSF-M30 x 1.5	1
18	18-20007	COVER		1
19	18-20006	COLLAR		1
20	18-20008	COLLAR		1
21		BEARING		1 SET
22		OIL SEAL	SC-405007	1
23	18-20009	BALL SCREW		1
24	18-20010	APRON		1
25	18-70023	COVER		1
26		CAP SCREW	M6 x P1.0 x 12L	6
27		SPRING WASHER	M8	8
28		SCREW	M8 x P1.25 x 30L	8
29		SCREW	M16 x P2.0 x 55L	8
30		SPRING WASHER	M16	8
31		OIL SEAL	TC-345007	1
32	18-20011	BRACKET		1
33		SCREW	M10 x P1.5 x 35L	4
34		BEARING		2
35		TAPER PIN	#6 x 45L	2
36	18-20012	COLLAR		1
37	18-20013	COLLAR		1
38		SET SCREW	M6 x P1.0 x 6L	3
39		NUT	YSR-M30 x 1.5	1
40		SCREW	M6 x P1.0 x 20L	4
41	18-20014	COVER		1
42		SCREW	M6 x P1.0 x 20L	4
43	18-40013	PRESSURE FLANGE		1
44		CLAMP ELEMENT	SCE300-16 x 20	2
45		SCREW	M10 x P1.5 x 40L	4
46		CLAMP ELEMENT	SCE300-25 x 30	2
47		PRESSURE FLANGE	25 x 30	1
48		SCREW	M6 x P1.0 x 20L	4
49		OIL SEAL	TC-456008	1
50		SCREW	M6 x P1.0 x 20L	4
51		SCREW	M10 x P1.5 x 30L	1
52		SPRING WASHER	M10	1
53	18-20015	WASHER		1
54		KEY	10 x 8 x 56L	1
55	18-20016	PULLEY		1
56		SCREW	M14 x P2.0 x 50L	4
57		SPRING WASHER	M14	4
58	18-20017	MOTOR BASE		1
59		SPRING WASHER	M14	4
60		SCREW	M14 x P2.0 x 50L	4

61	18-20018	FOUNDATION BOLT		6
62	18-20019	FOUNDATION PAD		6
63		NUT	M30	6
64		MOTOR		1
65		SCREW	M8 x P1.25 x 70L	1
66		NUT	M8	1
67	18-20022	BLOCK		1
68		SCREW	M8 x P1.25 x 30L	2
69		OIL SIGHT	LS-3"	1
70		SCREW	M10 x P1.5 x 30L	2
71		PLUG	PT 1/2"	1

6.4 BASE CASTING ASSEMBLY DRAWING




Base Casting Assembly

BASE CASTING ASSEMBLY PARTS LIST


REF	PART NO.	DESCRIPTION	PARTS NAME	Q'TY
1	18-20001	BED		1
2		SCREW	M16 x P2.0 x 55L	8
3		WASHER	M16	8
4	18-70019	BALL SCREW COVER		1
5		SCREW	M6 x P1.0 x 12L	22
6	18-20003	MOTOR BASE		1
7	18-70030	COVER		1
8	18-70020	COVER		1
9	18-20002	BASE		1
10	18-20018	FOUNDATION BOLT		6
11		NUT		6
12	18-20019	FOUNDATION PAD		6
13	18-70029	COVER		1
14	18-70028	OIL TANK		1
15		SCREW	M6 x P1.0 x 30L	11
16		PLUG	1/2"	2
17		OIL SIGHT	3"	2
18		SCREW	M10 x P1.5 x 30L	4
19	18-70017	COOLANT TRAY		1
20		HANDLE	4"	2
21		WHEEL	2-1/2"	4
22	18-70021	FILTER		1
23	18-70025	STOPPER		1
24	18-70024	COVER		1
25		SCREW	M8 x P1.0 x 25L	3
26		WASHER	M6	3
27	18-70022	PUMP	1/8HP	1
28	18-70038	PUMP BASE		1
29	18-20020	COVER		1
30	18-20021	PLATE		2
31		PLATE		2

6.5 ELECTRICAL CABINET DRAWING



Electrical Cabinet

6.6 HEADSTOCK DRAWING




HEADSTOCK PARTS LIST

PARTS LIST				
REF NO.	PART NO.	DESCRIPTION	PARTS NAME	Q'TY
1		SCREW	M8xPI,25x25L	1
2		SPRING WASHER	M8	1
3	18-10034	WASHER		1
4	18-1033F	PULLEY		1
5		KEY	7x7x45L	1
0		BELT	SPA1932	4
7		OIL SEAL	TC-306210	1
8		SCREW	M6xP1.0x30L	5
9		SNAP RING	RTW-62	1
10		REARING	6206	2
11	18-10003	FLANGE BEARING		1
12		O-RING	G-75	1
13		SNAP RING	RTW-62	1
14	18-1001F	HEADSTOCK		1
15	18-1012F	GEAR SHAFT		1
16		BEARING	6207	1
17		BEARING	6008	1
18	18-10006	COLLAR		1
19	18-10020	SHAFT		1
20		KEY	7x7x30L	2
21	18-101 IF	GEAR		1
22	18-10021	GEAR		1
23		SNAP RING	STW-68	2
24	18-10022	GEAR		1
25		BEARING	6207	1
26		BEARING	6207	1
27		SNAP RING	RTW-72	1
28		O-RING	G-65	1
29	18-10013	PLUG		1
30		SNAP RING	RTW-72	1
31		O-RING	G-65	1
32	18-10013	PLUG		1
33		SCREW	M6xP1.0x16L	6
34	18 10023	COVER		1
35		BEARING	6014Z	1
36		SNAP RING	STW-70	1
37	18-10028	COLLAR		1
38	18-10029	GEAR		1
39		KEY	10x8x25L	1
40		SCREW	M6xP1.0x16L	4
41	18-1054F	BRACKET		1

42		SCREW	M6xP1.0xI6L	3
43		KEY	5x5x17L	1
44		ENCODER	F21AK06DB16	1
45		SET SCREW	M3xPU.5x5L	2
46		CAP SCREW	M3xP0.5x6L	3
47		SNAP RING	STW-25	1
48	18-1055F	CLUTCH		1
49		O-RING	G-65	1
50	18-10031	SHAFT		1
51	18-10030	FLANGE BEARING		1
52		BEARING	6005	2
53		SCREW	M6xPI.0x20L	4
54	18-10032	GEAR		1
55		KEY	7x7x25L	1
56		SNAP RING	STV-25	1
57		NUT	YSF-M75x2	1
58		SET SCREW	M8xP1.25x8L	3
59		BEARING	32015	1
60	18 10024D	SPINDLE		1
61		NUT	YSR-M80X2	1
62		SET SCREW	M8xPI. 25x81,	3
63	18-10025	GEAR		1
64		KEY	12x8x85L	1
65	18-10026	GEAR		1
66		BEARING	32017	1
67	18-10027D	COVER		1
68		SCREW	M6xPI.0x40L	5
69	18-10014	SLEEVE		1
70	18-10049D	CAM		6
71	18-10052D	SPRING		6
72	18-10051D	SCREW		6
73	18-10050D	CAM BOLT		6

6.7 HEADSTOCK LUBRICATION SYSTEM DRAWING




Headstock Lubrication System

HEADSTOCK LUBRICATION SYSTEM PARTS LIST

REF NO.	PART NO.	DESCRIPTION	PARTS NAME	Q'TY
1		PIPE	φ 8 x 1000L	1
2		COMPRESSION BUSHING	PA-8	1
3		ELBOW ADAPTER	PH-802	1
4		PLUG	PT 1/2"	1
5		ELBOW ADAPTER	PT 3/4" x PE 3/4"	1
6		REINFORCED PLASTIC HOSE	3/4" x 900L	1
7	18-80024	LIMIT SWITCH		4
8		SPRING WASHER	M6	8
9		SCREW	M6 x P1.0 x 16L	8
10		LIMIT SWITCH		4
11		SPRING WASHER	M4	8
12		CAP SCREW	M4 x P0.7 x 22L	8

6.8 SADDLE DRAWING #1




SADDLE PARTS LIST

REF	PART NO.	DESCRIPTION	PARTS NAME	Q'TY
1	18-40015	COVER		1
2		NUT	YSR-M20 x 1	1
3	18-40025	WIPER COVER		1
4	18-40026	WIPER		1
5		CAP SCREW	M5 x P0.8 x 12L	4
6	18-40016	COLLAR		1
7	18-40032	COLLAR		1
8		BEARING		1 SET
9	18-40001	SADDLE		1
10	18-40002	CROSS SLIDE		1
11	18-40014	BALL SCREW		1
12		O-RING	P-5	1
13		TAPER PIN	#6 x 45L	2
14	18-40017	NUT BASE		1
15		SCREW	M8 x P1.25 x 35L	4
16	18-40018	SPACER		1
17	18-40024	SCREW		2
18		CAP SCREW	M6 x P1.0 x 12L	4
19	18-40021	GIB		1
20		SCREW	M10 x P1.5 x 35L	4
21	18-40019	STRIP		1
22	18-70026	COVER		1
23	18-40005	FLANGE BEARING		1
24		BEARING		2
25	18-40016	COLLAR		1
26	18-40009	COLLAR		1
27	18-40006	COVER		1
28		OIL SEAL	TC-304007	1
29		SET SCREW	M5 x P0.8 x 5L	2
30		NUT	YSR-M20 x 1	1
31		SET SCREW	M5 x P0.8 x 5L	2
32		SCREW	M8 x P1.25 x 20L	4
33		SCREW	M10 x P1.5 x 35L	4
34	18-40020	STRIP		1
35	18-40024	SCREW		2
36	18-40022	GIB		1
37	18-40033	DOG		3
38		SPRING WASHER	M5	6
39		SCREW	M5 x P0.8 x 12L	6
40		LIMIT SWITCH	GSBFD12-502	1
41		SCREW	M6 x P1.0 x 25L	4
42		SERVO MOTOR		1
43	18-80015	COVER		1
44	18-80014	COVER		1
45		NUT	M8	1
46	18-40008	BLOCK		1
47		SCREW	M8 x P1.25 x 40L	1
48		SCREW	M8 x P1.25 x 25L	2
49	18-40003	BRACKET		1
50	18-40012	COVER		2
51	18-40011	PULLEY		1
52		CLAMP ELEMENT	SCE300-16 x 20	1
53		SCREW	M5 x P0.8 x 20L	3
54	18-40004	COVER		1
55		BEARING		1
56		SNAP RING	STW-15	1
57	18-40013	PRESSURE FLANGE		1
58	18-40007	MOTOR BASE		1
59		SCREW	M8 x P1.25 x 20L	4
60	18-40010	PULLEY		1

61		SCREW	M5 x P0.8 x 20L	3
62		CLAMP ELEMENT	SCE300-16 x 20	1
63	18-40013	PRESSURE FLANGE		1
64		SCREW	M6 x P1.0 x 20L	6


6.9 SADDLE DRAWING #2



SADDLE 2 PARTS LIST


REF	PART NO.	DESCRIPTION	PARTS NAME	Q'TY
1		SCREW	M10 x P1.5 x 65L	4
2	18-40034	BLOCK		1
3	18-40036	TOOL POST		1
4	18-40037	SCREW		12
5	18-40038	SCREW		3
6		NUT	M20 x P2.5	1
7	18-40039	COLLAR		1
8		SET SCREW	M8 x P1.25 x 8L	3
9	18-40040	ROD		3
10	18-40041	SHAFT		1
11	18-40042	LOCKING BLOCK		1
12	18-40043	STOPPER		1
13	18-40044	SLEEVE		1
14		SPRING	1/4" x 1/2"L	1
15		SCREW	M6 x P1.0 x 16L	6
16		SCREW	M10 x P1.5 x 50L	4
17	18-40023	GIB		1
18		LIMIT SWITCH	SN02D12-502	1
19		CAP SCREW	M5 x P0.8 x 12L	4
20	18-40028	WIPER COVER		2
21	18-40027	WIPER		2
22	18-40024	SCREW		1
23	18-40033	DOG		3
24		SPRING WASHER	M5	6
25		SCREW	M5 x P0.8 x 12L	6
26		SCREW	M5 x P0.8 x 16L	2
27		SCREW	M5 x P0.8 x 16L	4
28		TAPER PIN	#7 x 80L	2
29	18-80012	LIMIT SWITCH		1
30	18-40029	WIPER		2
31	18-40030	WIPER COVER		2
32		CAP SCREW	M5 x P0.8 x 12L	4
33		TUBE	3/8" x 370L	1
34		ELBOW	3/8"	1
35		TUBE	3/8" x 50L	1
36		VALVE GATE	3/8"	1
37		TUBE	3/8" x 50L	1
38	18-40049	BLOCK		1
39		SPRAYING PIPE	3/8" x 12"L	1
40		SPRAYING PIPE	3/8" x 20"L	1
41	18-40035	BLOCK		1
42	18-40037	SCREW		6
43		SCREW	M12 x P1.75 x 20L	2
44		NUT	M16	1
45	18-40045	COLLAR		1
46	18-40046	SHAFT		1
47	18-40047	LOCKING BLOCK		1
48	18-40048	REAR TOOL POST		1
49		SCREW	M10 x P1.5 x 50L	4
50		PIPE	CT702-60"L	1
51		NIPPLE	3/8"PT x 3/8"PS	1
52		ELBOW	3/8"	1
53		SCREW	M6 x P1.0 x 40L	2
54		BLOCK	22 x 56L	1
55		FLEXIBLE HOUSE	ψ6 x 800L	1
56	18-40024	SCREW		1
57		CAP SCREW	M5 x P0.8 x 10L	4
58	18-80021	COVER		1
59	18-80020	BOX		1
60		SCREW	M6 x P1.0 x 12L	4

61		SCREW	M10 x P1.5 x 45L	4
62		SCREW	M10 x P1.5 x 30L	4
63		TAPER PIN	#6 x 40L	2
64		SCREW	M6 x P1.0 x 16L	3
65		BELT	HTD-560-5M-20	1
66		SCREW	M8 x P1.25 x 35L	4
67		CAP SCREW	M6 x P1.0 x 12L	7
68	18-80018	PLATE		1



Sheet Metal Assembly

6.11TAILSTOCK ASSEMBLY (End View) DRAWING




Tailstock Assembly– End View

TAILSTOCK ASSEMBLY (End View) PARTS LIST

TAILSTOCK				
REF NO.	PART NO.	DESCRIPTION	PARTS NAME	Q'TY
1	18-60010	LOCKING NUT		1
2	18-60009	LOCATING BOLT		1
3		SPRING PIN	ϕ 4 x 40L	1
4		SET SCREW	M6 x P1.0 x 8L	1
5	18-60015	CAM SHAFT		1
6	18-10039	SET SCREW		1
7	18-80029	DOG		1
8		SCREW	M5 x P0.8 x 12L	2
9		SPRING PIN	ϕ 4 x 30L	1
10		LIMIT SWITCH		1
11	18-80022	BOX		1
12		SCREW	M5 x P0.8 x 10L	2
13	18-80023	COVER		1
14		CAP SCREW	M5 x P0.8 x 10L	4

6.12 TAILSTOCK ASSEMBLY (Side View)



Tailstock Assembly– Side View

TAILSTOCK ASSEMBLY (Side View) PARTS LIST

REF NO.	PART NO.	DESCRIPTION	PARTS NAME	Q'TY
1		CENTER	M.T.#4	1
2	18-60003	QUILL		1
3		O-RING	G-65	1
4		CAP SCREW	M6 x P1.0 x 12L	3
5	18-60022	COVER		1
6	18-60001	TAIL STOCK		1
7	18-60008	HANDLE		1
8	18-60007	LEAD SCREW		1
9	18-60017	BOLT		1
10	18-60018	HANDLE		1
11	18-60017	BOLT		1
12	18-60006	NUT		1
13		SCREW	M6 x P1.0 x 16L	3
14		BEARING		1
15		BUSHING	70B-2515	1
16	18-60019	KEEP		1
17		SCREW	M8 x P1.25 x 25L	4
18		BEARING		1
19	18-60020	INDEXING		1
20		STEEL BALL	1/4"	3
21		SPRING	1/4" x 1/2"L	3
22	18-60005	HANDLE WHEEL		1
23		KEY	5 x 5 x 30L	1
24	18-60021	PLUG		1
25		SET SCREW	M8 x P1.25 x 30L	1
26		HANDLE	M10	1

TAILSTOCK ASSEMBLY (Side View) PARTS LIST

REF NO.	PART NO.	DESCRIPTION	PARTS NAME	Q'TY
27		SET SCREW	M6 x P1.0 x 10L	1
28	18-60013	PAD		1
29		SCREW	M6 x P1.0 x 20L	2
30	18-60028	STOPPER		2
31		SET SCREW	M5 x P0.8 x 20L	4
32	18-60025	WIPER COVER		2
33	18-60024	WIPER		2
34		SPRING WASHER	M10	2
35		SCREW	M10 x P1.5 x 60L	2
36	18-60004	CLAMP PLATE		1
37	18-60012	PIVOT BLOCK		1
38	18-60011	BOLT		1
39	18-60014	WASHER		1
40		NUT	M16	1
41		SCREW	M8 x P1.25 x 60L	2
42	18-60023	SCREW		2
43	18-60016	GIB		1
44	18-60002	BASE		1
45	18-60026	WIPER		2
46	18-60027	WIPER COVER		2
47		CAP SCREW	M5 x P0.8 x 12L	4