



The Toolroom Company

**MB-Q SERIES
FRYER / SIEMENS 828 CONTROL
MAINTENANCE MANUAL**



TABLE OF CONTENTS

1.0 - SAFETY INFORMATION

Safety information	3
1.01 Mechanical Safety	4
1.02 Electrical Safety	5

2.0 - BASIC INSTALLATION

2.1 WHERE TO PLACE YOUR MACHINE

2.11 Foundation	6
2.12 Environmental Conditions.....	6

2.2 UNLOADING YOUR MACHINE 6

2.3 RECEIVING YOUR MACHINE 6

2.4 UNPACK AND PLACE YOUR MACHINE 7

2.5 PRIOR TO THE ARRIVAL OF THE TECHNICIAN

2.51 Installation Safety Instructions	7
2.52 Cleaning & Lubricating Machine	7
2.53 Line Voltage Check	7
2.54 Electrical Precautions	7

2.6 LEVELING THE MACHINE 9

2.61 Leveling Procedure	9
-------------------------------	---

3.0 - GENERAL INFORMATION

3.1 MAINTENANCE SCHEDULE CHART 11

3.2 MACHINE COMPONENTS

3.21 Axis Lubrication System	12
3.22 Electrical System.....	12
3.23 Pneumatic System	13
3.24 Spindle / Headstock	14
3.26 Flood Coolant System	15
3.27 Fryer Tool Probe	16
3.28 Fryer Part Probe	17

3.3 BASIC MACHINE PROCEDURES

3.31 Set Axis Home Position	18
3.32 Check Axis Backlash.....	19
3.33 Adjusting Backlash Compensation.....	20
3.34 Working with Waycovers	20
3.35 Check / Adjusting Ballscrew Endplay	21
3.36 Check Axis Belts.....	21

4.0 - 828 CONTROL

4.1 ACCESSING MACHINE PARAMETERS 22

4.2 ACCESSING THE SOFTWARE VERSION..... 22

4.3 REVERT TO THE FACTORY SET PASSWORD..... 22

4.4 ADJUSTING INPUT VOLTAGE PARAMETERS 23

4.5 M-CODES 24

4.6 ALARMS

4.61 Siemens Alarms	25
4.62 Fryer PLC Alarms and Descriptions	25
4.63 Clearing an Alarm.....	26

4.7 WORKING WITH FILES

4.71 File Types	26
4.72 Back-Up An 828 Archive File to A USB Stick	26
4.73 Reloading an Archive File	27
4.74 Backing Up Tool Data on the 828 Control	27

4.8 ADDING A SOFTWARE OPTION TO AN 828 CONTROL 28

4.9 SETUP THE NETWORK DRIVE IN AN 828 30

5.0 – DRAWINGS AND PARTS LIST

5.1 828 CONTROL ELECTRICAL PANEL LAYOUT 32

5.2 828 CONTROL LAYOUT 33

5.3 828 3-HANDWHEEL OPERATOR CONSOLE 34

5.4 Z-AXIS COLUMN ASSEMBLY 35

5.5 MB-16 HEAD ASSEMBLY 37

5.6 MB-10/14 LOWER HEAD ASSEMBLY 40

5.7 MB-10/14 UPPER HEAD ASSEMBLY 43

5.8 Z-AXIS BALL SCREW ASSEMBLY 46

5.8 X-AXIS TABLE ASSEMBLY 48

5.9 X-AXIS BALL SCREW ASSEMBLY 50

5.10 Y-AXIS SADDLE ASSEMBLY 52

5.11 Y-AXIS BALL SCREW ASSEMBLY 54

5.12 Z-AXIS RAM ASSEMBLY 56

1.0 SAFETY INFORMATION

READ BEFORE INSTALLING OR OPERATING

NOTE: THIS MACHINE IS AUTOMATICALLY CONTROLLED AND MAY START AT ANY TIME.



All CNC machines contain hazards from rotating parts, belts and pulleys, high voltage electricity, noise, and compressed air. When using CNC machines and their components, basic safety precautions, including all appropriate LOTO procedures must always be followed to reduce the risk of personal injury and mechanical damage.

It is the machine owner's responsibility to make sure all personnel who are involved in installation and operation of this machine are thoroughly acquainted with the procedures and safety instructions provided herein *BEFORE* they perform any actual work.

Only Fryer factory-trained service personnel should troubleshoot and repair the equipment.

Do not modify or alter this equipment in any way without first consulting Fryer Machine. Any modification or alteration of this equipment could lead to personal injury and/or mechanical damage and could void your warranty.



EMERGENCY STOP (E-STOP) BUTTON

PRESSING THE EMERGENCY STOP BUTTON WILL INSTANTLY STOP ALL MOTION OF THE MACHINE, THE SERVO MOTORS, THE TOOL CHANGER, AND THE COOLANT PUMP.

1. Keep machine and area around it clean and well lit. Never allow chips, coolant, or oil to remain on the floor. Do not leave loose objects on or around machine.
2. Use appropriate eye and ear protection while operating the machine. ANSI-approved impact safety goggles and OSHA-approved ear protection are recommended to reduce the risks of eye injury and hearing loss.
3. Keep all loose clothing, hair, and jewelry away from the machine at all times.

4. Gloves are easily caught in moving parts. Take them off before using the machine.
5. Always wear safety shoes with steel toes and oil-resistant soles.
6. Do not paint, alter, deface, or remove any warning plates from the machine. Replacement plates are available from Fryer Machine Systems.
7. Keep flammable liquids and materials away from the work area and hot chips.
8. Coolant and oils can make surfaces on the machine slippery. They can also present an electrical hazard if the machine has power on. Therefore, do not stand on any part of the machine at any time.
9. Keep vises, clamps, fixtures, or work pieces from extending beyond the back edge of the table.
10. Check for damaged parts and tools before operating the machine. Any part of a tool that is damaged should be properly repaired or replaced. Do not operate the machine if any component does not appear to be functioning correctly.
11. Improperly clamped parts machined at high speeds/feeds may be ejected and puncture the safety door. Machining oversized or marginally clamped parts is not safe.
12. To avoid tool changer damage, ensure that tools are properly aligned with the spindle drive lugs when loading tools.
13. Windows must be replaced immediately if damaged or severely scratched – contact the factory for replacement panels.
14. Do not attempt to operate the machine before all the installation instructions have been completed.
15. Be sure to review the maintenance section of this manual for instructions to keep your machine running properly.

1.01 Mechanical Safety

1. Always press Emergency Stop when the machine is not in use.
2. Never operate the machine with any cover or shield open or removed.
3. Never reach into the work area when the spindle is turning or if the machine is in automatic mode.
4. Put the machine in manual mode and be sure last programmed function has been completed before reaching inside of the work area.
5. The functions of the machine make it impossible to eliminate all pinch points. Be particularly aware of the following pinch points:
 - a. Spindle and tool rotation
 - b. Table, saddle, and head.
6. Do not operate machine without axis motor covers or axis waycovers in place.
7. Report any loose, worn, or broken parts to your supervisor. The same action should be taken if any unusual noise or machine action occurs.
8. The electric components are protected from normal moisture resulting from humidity or use of water-based coolants. **DO NOT** however, use a water hose to clean the machine or the area around it.
9. Never touch a machine control device or electrical component when your hand is wet.
10. Never clean up chips while the machine is running or is in automatic mode.
11. Do not file workpieces being rotated under power.
12. At the end of the workday the machine should be placed in "EMERGENCY STOP MODE"

13. When restarting a machine after it has been shut down always assume it has been altered. Recheck all phases of the job as though you were running the first piece.
14. Never run the spindle until hands, feet, and body are well clear of the work area.

1.02 Electrical Safety

1. **WARNING:** Electrical enclosures contain high voltage. Disconnect equipment from power source before opening cabinets.
2. **Before replacing a fuse, switch off the machine.**
3. **Immediately turn off power if:**
 - Power problems develop
 - In the event of electrical storms.
 - Ambient temperatures exceed 105 degrees Fahrenheit (40 degrees C)
4. The electrical power must meet the specifications in this manual. Attempting to run the machine from any other source can cause severe damage and will void the warranty.
5. The electrical panel should always be closed and locked except during service.
6. When the main circuit breaker is on, there is high voltage throughout the electrical panel and some components operate at high temperatures, therefore extreme caution is required.
7. Do not reset a circuit breaker until the reason for the fault is investigated.
8. Never service the machine with the power connected.

2.0 BASIC INSTALLATION

2.1 WHERE TO PLACE YOUR MACHINE

Thank you for choosing Fryer Machine Systems. You have purchased a high quality, custom crafted machine tool designed and built to provide years of trouble-free service. To ensure that your machine is properly installed we ask that you review the following information prior to the shipment of your machine.

2.11 Foundation

Your foundation must be a minimum 6"(150mm) thick concrete slab floor and should be placed on a single slab with no seams. Be sure to leave space around the machine for leveling components and access to the electrical cabinet.

If your floor does not meet these specifications, contact the factory for further recommendations.

Install the machine on the first or second floor. Take the stress of ceiling and foundation into careful consideration to ensure that the machine load can be offset.

2.12 Environmental Conditions

Generally, the machine will be installed in the following conditions. However, these may change over a period of time or in response to seasonal changes.

- Supply voltage: +/- 10% of voltage listed on serial number tag.
- Source frequency: ± 2 Hz of frequency listed on serial number tag
- Temperature effects dimensional accuracy, therefore, ambient temperatures should not exceed 105 degrees Fahrenheit. Also avoid exposing the machine to direct sunlight or heat rays which can change the environmental temperature.
- Relative Humidity: Less than 80% (Temperature changes should not cause condensation)
- Atmosphere: Free from excessive dust, fumes, corrosive gases, and salt
- Avoid exposing the machine to abnormal vibration.

2.2 UNLOADING YOUR MACHINE

Fryer machines are shipped on skids designed for forklift offloading. Be sure your forklift is rated for the proper weight of the machine.

Note: If you are using a crane for offloading, please contact the factory in advance for instructions as damage can occur if supported in the wrong locations.

2.3 RECEIVING YOUR MACHINE

NOTE: If you have a door that is less than 8' wide x 10' high, please contact the factory prior to shipment so that we can make sure your machine is packaged to fit into your door openings.

1. Fryer machines are carefully packed to avoid damage in transit; however, we ask that you **UNWRAP AND INSPECT YOUR MACHINE AS THOROUGHLY AS POSSIBLE PRIOR TO SIGNING THE BILL OF LADING.** If a digital camera is available, pictures should be taken before the machine is moved further. Pictures should be sent to service@fryermachine.com.
2. Place the machine in its location and complete inspection. If there is any damage to your machine, Fryer should be notified immediately. This will enable us to provide replacement parts before the service technician arrives install the machine.
3. If you have any questions about any of these installation instructions or other questions about your new Fryer Machine Systems machine, please call the Fryer Service Department and one of our trained technical staff will be happy to assist you.

2.4 UNPACK AND PLACE YOUR MACHINE

To make certain that your machine installation goes smoothly, it is important that the following items are completed **prior** to the arrival of the Fryer authorized service technician. This will ensure that our technician is able to provide you with the maximum amount of training during his allocated time with you.

1. Have your rigger move the machine to the operating location, remove it from the skid and install on ALL leveling pads.
2. Remove all packaging material and thoroughly clean the machine and inspect for hidden damage.
3. Remove all large assemblies from skids and stage next to machine to facilitate ease of assembly.
4. Install leveling pads and level machine. Level with a precision level, using the leveling screws and pads provided with the machine.

2.5 PRIOR TO THE ARRIVAL OF THE TECHNICIAN

2.51 Installation Safety Instructions

Initial start-up of the machine must be performed by a Fryer Machine Systems authorized service technician.

2.52 Cleaning & Lubricating Machine

All protective coatings (cosmoline) must be removed before using the machine.

Be cautious when selecting a suitable cleaning agent. Paraffin applied with a clean brush will soften the protective coating. The protective coating can then be removed with clean rags.

- WD-40 or a similar product is recommended for cleaning the machine. Do not use gasoline or any other flammable solution to clean the machine.
- Clean all exposed ways of the bed and saddle.

2.53 Line Voltage Check

Line voltage must be $\pm 10\%$ of the voltage listed on the serial number tag.

**INITIAL POWER-UP SHOULD ONLY BE PERFORMED BY
A FRYER TECHNICIAN OR FACTORY AUTHORIZED
REPRESENTATIVE.**

2.54 Electrical Precautions

ELECTRICAL SCHEMATICS FOR YOUR MACHINE ARE LOCATED IN THE ELECTRICAL CABINET AND IN THIS MANUAL.

Wiring

1. Ensure that all local electrical codes are met.
2. Do not connect to the power distribution panel any power cables for devices that can cause line noise, such as welders and high frequency quenching machines.

Grounding

You should always refer to your local electrical code to be sure you are grounding to code. Generally, use a grounding wire with a cross section of more than 14 mm and a resistance to ground of less than 100 ohms. This wire size should be greater than AWG (American Wire Gauge) No. 5 and SWG (British Legal Standard Wire Gauge) No.6.

Generally, the machine should be grounded to a separate grounding rod. If an independent ground cannot be provided for the machine, prepare the ground connection as follows:

1. Connect a single conductor to its own grounding terminal. This will avoid possible serious accidents resulting from ground currents that might otherwise flow in the NC machine if a peripheral device should malfunction.
2. Be careful when using concrete reinforcing rods as grounding points. These reinforcing rods often are used to ground equipment because they usually offer a resistance to ground of less than 100 ohms. In doing so, make the connection as follows: (This also applies to connecting ground wires to regular grounding terminals)
3. Do not use the same grounding reinforcing rod or grounding terminal for other devices since this could lead to line noise such as produced electric welders and high frequency quenching machines.
4. Use a grounding terminal with an adequate electrical performance rating and which is durable.
5. A separate grounding wire should be used, one whose length is as short as possible.
6. Check the resistance to ground by actual measurement.
7. This should measure less than 100 ohms if the single device is connected to its own grounding rod.

Desirable Independent Grounding: Earth resistance: Less than 100 ohms **Common Grounds:**

Resistance to ground = $100/\text{the number of devices connected to the grounding } (\Omega)$

NEVER GROUND EQUIPMENT IN SERIES!

Connection of Power Line

NOTE: Electrical installation should only be completed by a qualified electrician.

1. Make sure that the incoming power is compatible with the requirements of the machine tool (voltage, amperage, phasing). All this information can be found on the machine's serial number tag.
2. Power wires, grounding and over-voltage protection should comply with the local electrical code.
3. **DO NOT** connect if the incoming power is different from the power requirements of the machine. Contact a qualified electrician.

2.6 LEVELING THE MACHINE

Before attempting to use the machine, it will be necessary to accurately level it.

- Screw the leveling bolts (with nut) into the holes in the base of the machine. Set a leveling pad under.
- Please prepare the following tools to adjust machine level:
 - Precision level (0.0005"/ft. or 0.013mm/1000mm accuracy)
 - Two adjustable 32mm wrenches
- Clean the bed way and cross slide surfaces thoroughly and set one of the precision levels on the flat bed way in the longitudinal direction, and the other on the cross slide, perpendicular to the first (if there is only one level available, then use it on both directions alternately).
- Adjust the six leveling bolts located the bottom of the machine base until the machine is leveled to within 0.001"/ft. (0.08mm/1000mm) in both directions.
- Lock the nuts on the leveling bolts, and re-check to see whether the level of machine is still correct. Repeat as necessary until machine level is obtained with leveling bolts locked.
- After initial installation, check the level once a week for the first month, then check monthly thereafter.

2.61 Leveling Procedure

Step 1

- Set up your precision level in the middle of the machine table parallel to the X-axis.
- With the table centered in the X and Y-axis, adjust the machine's four outside leveling studs to achieve level.
- Be sure that the center leveling pads are not touching and that all four outside pads have load.
- Also check to make sure that the machine casting is not touching the floor.



Step 2

- Now rotate the level 90 degrees so it is parallel to the Y-axis and again check level.
- Adjust the four outside leveling studs as needed.
- If any adjustments are required to achieve level, you must go back and re-check level with the level parallel to the X-axis.
- Repeat the adjustment process until the machine is perfectly level with the level parallel to both axes without further adjustment.



Step 3

- Adjust the center leveling studs until they are just touching.
- Again, verify the machine is level with the level parallel to both axes without further adjustment.

Step 4


- With the level parallel to the X-axis, slowly move the table back and forth over full Y-axis travel check to see that the level does not change. Make any required adjustments to achieve level.

Step 5

- Re-center the table in the Y-axis and again verify that the machine is level with the level parallel to both axes.
- Check that all leveling pads have some degree of load.
- Lock the nuts on the studs once the correct level is achieved.

Step 6

- The final check is “trammig” of the head. This is accomplished by mounting the indicator base on the spindle nose and setting the indicator tip on the tabletop at position “0” shown below. Properly load the indicator tip and zero the indicator at position “0”. Sweep the indicator tip by rotating the spindle manually over a 12” diameter circle. The indicator should show no more than .0005” total indicator reading. Record the values found at positions 1, 2, and 3.

TABLE SWEEP		<u>.0005"</u> OVER 12" DIAMETER IN X-Y AXIS	1.
			2.
			3.

3.0 GENERAL INFORMATION

3.1 MAINTENANCE SCHEDULE CHART

***FOR FURTHER MAINTENANCE DETAIL, REFER TO THE MACHINE COMPONENT SECTIONS IN THE MANUAL LISTED BELOW.**

CAUTION! Always follow all Lock Out / Tag Out procedures before performing any maintenance

MAINTENANCE ITEM	MAINTENANCE ITEM	Daily	Weekly	6 Mo	As Required
Check air pressure gage	See Pneumatic Section 3.203	X			
At the end of the day remove and dispose of chips	Use of brush or vacuum is recommended. Do not use air as it can push chips into ways and ballscrews.	X			
Check axis lubrication pump oil level	See Section 3.201 – Use Mobil Vactra #2 (ISO 68) or equivalent	X			
Check pneumatic (air) lubrication oil	Add Mobil ALMO break free synthetic air tool oil (5W-10W)		X		
Oil Cups on Headstock for Quill and Gearbox	See Section 3.24 for details - Use Mobil Vactra #2 (ISO 68) or equivalent		X		
Check coolant level	Complete a visual inspection		X		
Check machine level	See Section 2.61 for details			X	
Check axis backlash	See procedure in Section 3.43			X	
Remove and clean underside of waycovers / check sliders and bumpers for wear and/or damage	See Section 3.444 for details			X	
Check wipers for adjustment / damage	See Section 3.444 for details			X	
Check ballscrew endplay	See procedure in Section 3.45			X	
Check axis motor belts	See procedure in Section 3.46			X	
Change coolant	Blasocut BC40 NF-PL or equivalent				X
Check and change electrical cabinet air filters	Use Purolator A23465 air filters				X
Grease Point on Headstock for Gearbox	See Section 3.24 for details - Use Mobil 1 Synthetic grease or equivalent				EVERY 3 MONTHS

3.2 MACHINE COMPONENTS

3.21 Axis Lubrication System



- The automatic way lube system is controlled by the PLC in the control. The system only pumps way oil when the spindle and axes are moving. If there is no machine movement the pump will not pump unnecessary oil. This method greatly reduces way lube usage and keeps oil out of the machine coolant sump and prevents fouling.
- If the machine has been unused for more than 48 hours press the blue pushbutton on the side of the lube tank for approximately 30 seconds to pump oil to the ways. The pressure gage on the tank will indicate if it is working properly.
- If the system detects low way lube it will display the following message in the control: 700040 - WAY OILER PRESSURE FAULT

3.22 Electrical System

- Schematics (1) – The Electrical and Pneumatic Schematics are inside electrical cabinet
- Cabinet Filter Type (2) – Purolator A23465 or equivalent
- Check Filter Interval - Weekly
- Change Filter Interval – As Required (depending on environment)



3.23 Pneumatic System



- Schematic – See Pneumatic Schematic in electrical cabinet (see previous page)
- Pneumatic List / Pressure Settings
 - Main Supply – 90-125 PSI at 5 CFM
 - Air Gun
 - Drawbar
 - 4th Axis Brake (optional)
 - Spray Mist – Adjustable on spray mist unit (optional)
 - Programmable Air Blast – Adjustable (optional)
 - Quill Glass Scale Purge – Set Regulator to 11.6–17.4 PSI (Optional)
- Lubrication Requirements – Mobil Almo break free synthetic air tool oil 5W-10W or equivalent
- Check Lubrication Interval – Weekly – Add as needed

3.24 Spindle / Headstock – CAT 40, 4,500 RPM Spindle

Thermal expansion of the machine components can jeopardize machining accuracy. To prevent this condition always warm the machine up.

SPINDLE WARM UP – Use the chart below for daily startup

Warm Up Cycle	10 minutes @ 25% of maximum speed
	10 minutes @ 50% of maximum speed
	10 minutes @ 75% of maximum speed

SPINDLE DUTY RATING – Follow the duty rating outlined below

- If it is required for the spindle to run continuously (24 hours a day), the spindle must not run above 80% of the maximum RPM.
- If it is required for the spindle to run at maximum RPM, the spindle must not run more than 2 hours straight. After 2 hours of run time at maximum RPM, the spindle must be slowed down to 50% of the maximum RPM for at least 30 minutes before running at the maximum RPM again.

Headstock

- The headstock on your MB-Q has two oil cups. One is for lubrication of the quill and the other is for the lower end of the gearbox. See pictures below. Use Mobil Vactra #2 or equivalent at both points at a weekly interval.
- The headstock also has a grease fitting for the gearbox. Add grease every three months and use Mobil 1 Synthetic grease or equivalent.


Quill Lubrication



Gearbox Lubrication



Grease Fitting for Gearbox



3.25 Flood Coolant System

The flood coolant system consists of a submersible flood pump mounted in the base casting of the machine. The flood line runs up the back of the column and through the Z-axis cable track. It splits at a y-fitting in the headstock where it runs to two separate lengths of loc-line.

- The submersible flood pump is mounted behind the access panel shown below.
- The sump can be drained for coolant changes by using a wet vacuum.



3.26 Fryer Tool Setter (Tool Probe)

The Fryer Tool Probe can only be used to automatically measure tool length. It cannot be used to measure tool diameter or radius. Optional tool setting probes are available to perform length and diameter or radius measurements.

Tool Setter Calibration

If you ordered the tool probe during the original build of the machine it will have already been mounted to the machine table and tested at the factory. However, it must be calibrated before using it to set up your tool length offsets.

1. Install the tool probe in the reamed hole in the table and make sure that it is plugged in.
2. Set up a tool holder with a 1/2" dowel pin installed.
3. Use the **NEW TOOL** key to create the setup tool in the tool library as a 1/2" tool using the default name **CALIBRATION TOOL**.



10		CALIBRATION TOOL	1	1	0	-18.5250	0.5000												
----	--	------------------	---	---	---	----------	--------	--	--	--	--	--	--	--	--	--	--	--	--

4. Complete a tool change to this tool so that it will be active in the control.
5. Set a negative tool length offset for the **CALIBRATION TOOL** by measuring the distance from the tip of the dowel (while Z is at machine zero) to the top of the table surface.
6. Make sure your active work offset is zero in the Z-Axis.
7. Use paper, shim stock, or a gauge block to touch the dowel to the table.
8. Press **MEASURE TOOL** key
9. Press **LENGTH MANUALLY** key
10. Select **WORKPIECE**
11. Type the thickness of the paper, shim, or gauge block into Z0
12. Press **SET LENGTH** key

Now position the dowel approximately 1/4" above the probe in Z and roughly over the center of the probe

1. Select **MEASURE TOOL**
2. Select **CALIBRATE PROBE**
3. Select **LENGTH ONLY**
4. Press **CYCLE START**
5. The tool will move down in the Z axis and touch the top of the probe.
6. Once finished the tool will move back up.
7. Select **BACK** twice to exit the calibration screen and go to the **MANUAL** screen.

Calibration is now complete.



3.27 Fryer Part Probe

The Fryer Part Probe can only be used to automatically measure X and Y axis positions. It cannot be used to measure in the Z axis. Optional part probes are available to perform 3-axis measurements.

If you ordered the part probe during the original build of the machine it is located in the tool library where manual tools are stored. However, it must be calibrated before using it to set up your work offsets.

Fryer Part Probe Calibration

1. To set up a new FRYER probe in the tool table, it needs to be in the manual tool location in the library. It is important to remember your probe is wired which is manually inserted and removed the tool from the spindle.
2. Define the tool as a **3D probe**. When adding the new tool, you will need to press the **other** button to access the **3D** tool option. It is important that you fill out the correct tool diameter.

	3D_PROBE	1	1	0	-20.5340	0.3938	
---	----------	---	---	---	----------	--------	---

3. Load the probe into the spindle. Make sure the control recognizes the probe.
4. A ring gage is required for this next step. (A 2" diameter gage is recommended).
5. If a different diameter is required, change parameter **MD51770** to change diameter dimension. Refer to Section 4.1 for directions to access parameter screens.
6. Mount the gage to the machine table and use an indicator to find the center of the gage.
7. Once in the center, set a work offset in the middle. Make sure the offset is called up in the control.
8. Position the part probe at X and Y zero (middle of the gage). The Z axis should be roughly 1/4" below the top of the ring gage.
9. Select **WORKP. ZERO**
10. Select **CALIBRATE PROBE**
11. Select **DIAMETER**. The diameter value must equal the diameter of your gage.
12. Press **CYCLE START**. Once complete the probe should be calibrated in the X and Y axis.
13. At this point the part probe is calibrated and ready for use.
14. Remove the ring gage and store it in a safe place.



3.3 BASIC MACHINE PROCEDURES

3.31 Setting Axes Home Positions

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY

The 828 control comes standard with absolute encoders which generally do not require homing. However, if you have an issue with the battery or the machine is not turned on for an extended length of time the machine may need to be re-homed according to the following procedure. In addition, if an axis motor is removed or there is an issue with a motor coupling or pulley / belt assembly, one or more axes may need to be re-homed.

- Refer to Section 4.1 for directions to access parameter screens.
 1. Press **MENU SELECT**
 2. Select **SETUP**
 3. Select **MACHINE DATA**
 4. Select **AXIS MD**
 5. Select **SEARCH**
 6. Enter **34210 [0]** in the search field (This will read **ENC_REFP_STATE**)
 7. Select **OK**
 8. Select the proper axis with the **AXIS + AND AXIS -**
 9. Change the parameter **34210 [0] to 0** for an axis with a motor encoder
 10. Change the parameters **34210 [0]** and **34210 [1] to 0** for an axis with a scale
 11. Press **INPUT**
 12. Cycle power to machine leaving it off for a minimum of 30 seconds
 13. **Take extreme caution now as the machine can be crashed!**
 14. Line up the home markers for all axes that need to be homed
 15. Press the **E-STOP** button to turn off the servos
 16. Press **MENU SELECT**
 17. Select **SETUP**
 18. Select **MACHINE DATA**
 19. Select **AXIS MD**
 20. Select **SEARCH**
 21. Enter **34210 [0]** in the search field (This will read **ENC_REFP_STATE**)
 22. Select **OK**
 23. Select the proper axis with the **AXIS + AND AXIS -**
 24. Make sure Parameter **34210 [0]** and **34210 [1]** (if axis has a scale) **are set to 0**. If it is not, it is probable that the wrong axis is selected.
 25. Change the parameter **34210 [0] to 1** for an axis with a motor encoder
 26. Change the parameters **34210 [0]** and **34210 [1] to 1** for an axis with a scale
 27. Press **INPUT**
 28. Turn the feed rate override all the way down
 29. Pull the **E-Stop** button out
 30. Select **RESET**
 31. Press **HOME RETURN** (should say Jog Ref at the top of the screen)
 32. For a mill, press **AXIS+** (refers to the hard key on the manual panel you have selected)
 33. When done make sure parameter **34210 [0]** shows **2** for all axes (axis with motor encoder)

34. When done make sure parameter **34210 [0]** and parameter **34210 [1] shows 2** for all axes (axis with scale)

3.32 Check Axis Backlash

Tools Required: 0.0001" resolution dial indicator, remote handwheel (manual pulse generator)

- Set the indicator along the axis which is being measured. The needle should be in contact with a flat machined surface and the base on a stable, fixed point. See the pictures below which illustrate the setup for the X, Y, and Z axes.
- Using the remote handwheel, move the axis in one direction either positive or negative until the indicator is loaded by 0.002".
- Zero the indicator.
- Move the axis in the same direction by 0.005".
- Reverse the direction of the axis by 0.005".
- The additional amount that is needed to reach zero after the 0.005" reverse in direction is the backlash measured.
- This shows the loss of motion in the axis from the ballscrew and linear guide rails. Backlash compensation can be adjusted according to the procedure outlined below in *Section 3.33*.

X-Axis



Y-Axis



Z-Axis



3.33 Adjusting Backlash Compensation

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY

- Refer to Section 4.1 for directions to access parameter screens.
 - Press **MENU SELECT**
 - Select **SETUP**
 - Select **MACHINE DATA**
 - Select **AXIS MD**
 - Using **AXIS+ AND AXIS-**, select the correct axis
 - Select **SEARCH**
 - Enter **32450 [0] or 32450 [1]** if the machine is equipped with glass scales on the selected axis
 - Adjust the backlash on each axis
 - Select **SET MD ACTIVE (cf)**
 - Select **RESET (po)** to reboot the control

3.34 Working With Waycovers

- When working with steel waycovers, several precautions must be taken:
- Do not put excessive weight on the waycovers (50lbs. max.)
- Protective gloves should be worn while handling waycovers, as the metal edges can be sharp.
- Covers should be cleaned regularly to avoid any build-up of chips or debris. It is recommended that the underside of the covers be thoroughly cleaned at least every 6 months.

To remove the waycovers for service:

- Jog the axis being worked on so that the cover to be removed is in the fully compressed position.
- Next, remove the cap head screws attaching the cover to the moving axis and to the waycover standoff (if applicable).
- The waycover can now be removed by simply pulling it off the way surface.

To check waycovers for wear and/or damage:

- Make sure the covers slide open and closed freely and that there are no dents or visible damage that would impair free movement of the covers.
- Inspect the plastic sliders and rubber bumpers under the waycover to make sure they are in place and not damaged or worn.

To reinstall the waycovers on the machine:

- Slide the cover on the appropriate way surface making sure that it is clear of debris.
- Insert the cap head screws to the moving axis and the standoffs (if applicable) and **hand tighten only**.
- To properly align the waycover, jog the axis to the position where the waycover is in full extension, and then full compression.
- With the waycover fully compressed, all cap head screws can now be tightened.
- Run the axis back and forth slowing over full travel check for any visual signs of misalignment.
- Now rapid the axis back and forth over full travel again check for any signs of misalignment.

3.35 Check / Adjusting Ballscrew Endplay

* It is important to read and understand the procedure 3.34 *Working with Waycovers*, before executing this procedure.

- Tools Required: 0.0001" resolution dial indicator, remote handwheel (manual pulse generator), metric allen key set, spanner wrench.
- Check Endplay: You will need to access the pulley end of the ballscrew for the axis being worked on. To do this, remove the left side waycover and the belt cover for the X-axis. Remove the front waycover and belt cover for the Y-axis. The top end of the z-axis ballscrew is accessible by just moving the head down. Place a dial indicator needle on the end of the ballscrew. Load and zero the indicator appropriately. Using the remote handwheel set to x100 for the appropriate axis, change axis direction back and forth and observe any axial motion shown on the indicator. Endplay should be no more than .0001". This can also be accomplished by jogging each axis using the manual panel buttons or manually by using an allen wrench on the end of the ballscrew.
- Adjusting Endplay: If ballscrew endplay is greater than 0.0001", it must be adjusted. To do so, loosen the 3 set screws on the ballscrew spanner nut adjacent to the motor coupling. Using a spanner wrench, tighten the nut. The ballscrew will have to be held stationary with an allen key on the opposite end. Tighten the set screws and recheck the endplay. Repeat the tightening procedure if necessary. Once the ballscrew endplay is .0001" or less, re-install any sheet metal or motor covers and re-install the waycover(s) as applicable.

3.36 Check Axis Motor Belts

- The axis motors are connected to the ballscrews via pulley driven belts. Belts should be checked for excessive wear and proper tension at least every 6 months.
- To access the belts, remove left side belt cover for the X-axis and the front belt cover for the Y-axis.
- The Z-axis belt is located on the top of the column
- Once you have gained access to the belts, inspect them for any visible signs or wear or damage. Once the belts are considered acceptable, check each belt for proper tension.
- Belt tension is adjusted by loosening the slotted motor plate and sliding the motor-plate assembly to tighten or loosen the belt as required. Double check all hardware is properly tightened once the belt tension is correct.
- After the inspection is complete and any adjustments made, re-install the belt covers.

4.0 828 CONTROL

4.1 ACCESSING MACHINE PARAMETERS

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY

 **WARNING**

Malfunctions of the machine as a result of incorrect or changed parameter settings

As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death.

- Protect the parameterization (parameter assignments) against unauthorized access.
- Handle possible malfunctions by taking suitable measures, e.g. emergency stop or emergency off.

1. Press **MENU SELECT**
2. Select **SETUP**
3. Select **MACHINE DATA**
4. Available folders: **GENERAL MD / CHANNEL MD / AXIS MD**

4.2 ACCESSING THE SOFTWARE VERSION

To find out the version of the software you are running on your 828 control:

1. Press **MENU SELECT**
2. Select **DIAGNOSIS**
3. Select **VERSION**
4. The Software Version number is on the first line and will read: **"V##.## + SP ## + HF ##"**

4.3 REVERT TO THE FACTORY SET PASSWORD

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY

1. Press **MENU SELECT**
2. Select **SETUP**
3. Select **SET PASSWORD**
4. Enter the password: **SUNRISE**
5. Press **OK**
6. The lower part of the screen should now read "Current Access Level: Manufacturer"

4.4 ADJUSTING INPUT VOLTAGE PARAMETERS

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY


The Siemens control will shut itself off if the line voltage is more than 10% different than the voltage set in the control. You must adjust the parameter to match your line voltage to the machine.

The first step to accurately measure your line voltage. There are two ways to do this.

- Measure the incoming line voltage across all three legs with a voltmeter. Average your readings and write down the value.
 - OR -
- Read the line voltage from the control, follow the following steps:
 - **MENU SELECT** key
 - **SETUP** key
 - **INFEEED PARAMETER** key
 - Find **r25[0]** = and write down the voltage value in this parameter.
- Now you have the proper line voltage value to enter in the control.

Follow the steps below:

- Press E-stop
- **MENU SELECT** key
- **SETUP** key
- Press \wedge (up arrow hard key next to machine hard key)
- **DRIVE SYSTEM** key
- **SUPPLY** key
- **POWER DATA** key See screen below:



- Scroll down to the **Device Supply Voltage** field like in the screen shot above. Enter the line voltage value you obtained in the previous steps, press enter
- Press **ACCEPT** key
- There will be a message that states, "Confirm You Want to Change the Parameter", Press **YES** key to accept the change
- You are done.

4.5 M-CODES

An M code in CNC programming controls miscellaneous machine functions, including starting and stopping specific actions or programs.

M00	PROGRAM STOP
M01	OPTIONAL PROGRAM STOP
M02	END OF PROGRAM
M03	SPINDLE CLOCKWISE
M04	SPINDLE COUNTERCLOCKWISE
M05	SPINDLE STOP
M06	TOOL CHANGE REQUESTED
M07	MIST COOLANT / AIR BLAST ON
M08	FLOOD COOLANT
M09	COOLANT (FLOOD AND MIST / AIR BLAST) OFF
M10	INDEXER CYCLE START WAIT FOR COMPLETION
M11	MISC. MCODE M11=ON
M12	MISC. MCODE M12=OFF
M13	A AXIS BRAKE ON
M14	A AXIS BRAKE OFF
M17	END OF MACRO PROGRAM
M19	SPINDLE ORIENT
M23	2ND PROGRAMMABLE AIR BLAST ON
M24	2ND PROGRAMMABLE AIR BLAST OFF
M30	END OF PROGRAM
M54	DRAWBAR ON
M55	DRAWBAR OFF

Note: M-codes may change depending on options the machine is equipped with.

4.6 ALARMS

An alarm will be displayed once a fault occurs.

! *Warning: If you do not heed an alarm that is issued and do not resolve the cause of the alarm, it can present a hazard to the machine, the work piece, the saved settings, and in certain circumstances, may cause injury.*

4.61 Siemens Alarms

1. If a familiar alarm number / description appears carefully check the machine and resolve the cause of the alarm.
2. If you are unfamiliar with the alarm in question, proceed to the alarm list as follows:
 - a. Press **MENU SELECT**
 - b. Select **DIAGNOSTICS**
 - c. Select **ALARM LIST**
3. *Once "**ALARM LIST**" has been selected, press **HELP** key and additional information will be provided on the control screen.

4.62 Fryer PLC Alarms and Descriptions

There are certain PLC alarms in the 700000 range which are not in the **HELP** screen. These are FRYER Machine specific alarms that are for optional equipment installed on the machine. The alarms are listed below:

700000	ATC CAROUSEL NOT REFERENCED: EXECUTE M61
700001	LOW WAY LUBE [I32.6]
700002	LOW AIR PRESSURE [I32.2]
700003	HOME REQUIRED! PRESS CYCLE START
700004	PROBE ERROR / SIGNAL LOSS
700005	GEAR CHANGE FAULT
700006	SPINDLE OUT OF GEAR
700008	CHILLER FAULT
700009	HYDRAULIC PRESSURE FAULT
700011	THRU SPINDLE COOLANT FAULT, CHECK COOLANT SUPPLY
700013	EMERGENCY STOP PRESSED DURING TOOL CHANGE
700014	COUNTER-BALANCE CYLINDER PRESSURE LOW!
700015	ATC CAROUSEL TIMED OUT-CHECK THERMAL MCCAR
700016	CAROUSEL CANNOT INDEX POT NOT RETRACTED
700024	M52-TOOL POT DOWN TIMED OUT
700025	M53-TOOL POT UP TIMED OUT
700026	M69 CAUSED SERVO OFF
700027	M62 TIMED OUT CHECK TC HEIGHT,ORIENT, THERMAL MCATC
700028	M63 TIMED OUT CHECK THERMAL MCATC
700029	M54 DRAWBAR ON TIMED OUT
700030	M55 DRAWBAR OFF TIMED OUT
700032	CONTOUR HANDWHEEL ACTIVE
700033	Z MOTION AND ATC ARM NOT AT HOME POSITION
700034	RESET SUPPRESSED UNTIL TOOL CHANGE COMPLETION
700035	HOME RETURN: DEPRESS CYCLE START
700037	REPLACE PROBE BATTERY
700038	TOOL SETTER ACTIVE
700039	PART PROBE ACTIVE
700040	WAY OILER PRESSURE FAULT
700041	DOOR IS OPEN ~ CLOSE DOOR; PRESS CYCLE START TO CONTINUE
700042	Y AXIS MOTION AND ATC ARM NOT AT HOME POSITION

700043 DRAWBAR FAILURE

700044 QUILL SCALE POSITION UPDATE ON PRESS BUTTON AGAIN TO TURN OFF

4.63 Clearing an Alarm

1. Carefully check the machine according to the description given in the alarm. Clarification of the alarm codes can be found by using the **HELP** as described above.
2. Resolve the cause of the alarm.
3. Press **RESET**
4. Certain alarms will require a reboot of the control to clear.

4.7 WORKING WITH FILES

4.71 File Types

- **NC** archive contains the machine **PARAMETERS**
- **PLC** archive contains the **LADDER LOGIC** for the machine functions
- **DRV** archive contains the **AXIS DRIVE SETTINGS**

4.72 Back-Up An 828 Archive File to A USB Stick

For a download of the machine archive to a USB , press these three keys at the same time on the control:

CTRL + ALT + S

This will create a complete standard Easy Archive (**.ARD**) on a **USB**.

If a specific file or additional files need to be backed up to a **USB**, do the following:

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY

1. Select the **MENU SELECT**.
2. Select the **STARTUP**.
3. Press the **SYSTEM DATA** key. The data tree will open.
 - i. In the data tree, select the required files from which you want to generate an archive.
4. Press the **ARCHIVE** and **GENERATE ARCHIVE** keys.
5. The **GENERATE ARCHIVE: SELECT STORAGE LOCATION** window opens. Select the **USB** location for archiving.
6. Save the file as serial number of machine and the file name (i.e., for drive archive: "25123DRV")
7. Enter a name and press the **OK** key. The directory is created below the selected folder.
8. Press the **OK** key.
9. Select the format archive **ARD** for 828, enter the desired name and press the **OK** key to archive the file/files.
 - a. A message informs you if archiving was successful.
10. Press the **OK** key to confirm.
11. An archive file in the **.ARD** (828) format type is created in the selected directory.

*Note: When backing up an entire machine you should generate an individual file for NC, PLC, Drive, and HMI. When that step is completed, you should generate an archive for all these together.

4.73 Reloading an Archive File

PROCEDURE TO BE PERFORMED BY QUALIFIED PERSONNEL ONLY

NOTE: Set the password protection to “Current Access Level: Manufacturer”. Refer to Section 4.3 above.

1. Select the **PROGRAM MANAGER** key.
2. Press the **ARCHIVE** and **READ IN ARCHIVE** keys.
3. Select the archive storage location (i.e., **USB**) and position the cursor on the required archive.
4. Note: When the option is not set, the folder for user archives is only displayed if the folder contains at least one archive.

OR

5. Press the **SEARCH** key and in the search dialog, enter the name of the archive file with file extension **ARD** if you wish to search for a specific archive and press the **OK** key.
6. Press the **OK** or **OVERWRITE ALL** key to overwrite existing files.

OR

7. Press the **DO NOT OVERWRITE** key if you do not want to overwrite already existing files.

OR

8. Press the **SKIP** key if the read-in operation is to be continued with the next file.
9. The **READ IN ARCHIVE** window opens and a progress message box appears for the read-in process.
10. You will then obtain a **READ ERROR LOG FOR ARCHIVE** in which the skipped or overwritten files are listed.
11. Press the **CANCEL** key to cancel the read-in process.

*Note: You may only archive one file at a time.

4.74 Backing Up Tool Data on the 828 Control

Note: Setup data from part programs can only be backed up if they have been saved in the **WORKPIECES** directory.

For part programs, which are located in the **PART PROGRAMS** directory, **SAVE SETUP DATA** is not listed.

1. Select the **PROGRAM MANAGER** operating area.
2. Position the cursor on the program whose tool and zero-point data you wish to back up.
3. Press the **>>** and **ARCHIVE** keys.
4. Press the **SETUP DATA** key.
5. The **BACKUP SETUP DATA** window opens. Select the data you want to back up.
6. Change the specified name of the originally selected program in the **FILE NAME** field, if needed.
7. Press the **OK** key.
8. The setup data will be set up in the same directory in which the selected program is stored as an INI file.

4.8 ADDING A SOFTWARE OPTION ON THE 828 CONTROL

When you receive your machine all license numbers applicable to your order are activated prior to the machine leaving the factory. If you purchase a control option after the machine arrives at your facility you will receive a license number to active on your control. The license will either require you to go online and create a new license key, or this will be already done for you. If you receive a license certificate like pictured in figure one go to step 1, if not and you already have a license (see figure 2) then proceed to step 8 .

1. You need to obtain the hardware serial # (this not the same as the control serial number) follow these steps:

- Press **MENU SELECT**
- Press **SETUP**
- Select **LICENSE** (you may have to press the ^ or > key to see the soft key)
- Record the **CF CARD SERIAL #**

This number can also be found in the CF card located in your electrical cabinet. The number on the card is labeled as CFC SN. **CAUTION:** Machine must be powered down before the card is removed.

2. Once you have obtained your Control Hardware Serial Number you are ready to activate your new license number. Using the internet, log onto: www.Siemens.com/Automation/License

- Click on the link for **DIRECT ACCESS**
- Enter the **LICENSE # AND DISPATCH NOTE #** from the paperwork into the areas indicated on the web page.



3. Click **NEXT**

4. On the next screen enter your hardware serial number.

5. Next select the control model. Your machine has a 828.

6. The system will now return a software license key

7. Download PDF and save for your records. Also print the PDF so you can refer to it at the machine to type in new license key.

8. Already have printed license see below:



9. Follow step 1 to get to the license screen. Type in (overwriting old license key) current license key and press input. The field is highlighted, make sure to enter correctly.




Figure 3

10. Press all options soft key
11. Search for the particular option you want to activate. Set the box with the select key. See figure 4.




Figure 4

12. Press back soft key and power machine down. When you turn the machine back on the option should be activated.

4.9 SET UP THE NETWORK DRIVE IN THE 828


! NOTE: *It is recommended that this procedure be performed by an experienced network administrator.*

The transfer of programs can be achieved by mapping a soft- key to a networked computer. The soft key will appear in the Program Manager screen of the controller.



The computer connected to the network must be configured with a unique username and password. This information will be required for inputting on the controller. A dedicated shared folder is required on the PC for the storage of files.

- Refer to Section 4.1 for directions to access parameter screens.

1. Press **MENU SELECT**
2. Select **SETUP**
3. Select **START-UP**



4. Press the **HMI** and **LOG. DRIVE** keys. The **SET UP DRIVES** window opens.
5. Select the open key that you want to configure (**example #5**).
6. To allow entry fields to be edited, press the **CHANGE** key.
7. Select the data for the corresponding drive or enter the necessary data.




8. Press the **OK** key. The entries are checked. A window with the appropriate message opens if the data is incomplete or incorrect. Acknowledge the message with **OK** key. If you press the **CANCEL** key, then all of the data that has not been activated is rejected.
9. Restart the control in order to activate the configuration and to obtain the keys in the **PROGRAM MANAGER** screen.



5.0 – DRAWINGS / PARTS LISTS

5.1 828 CONTROL ELECTRICAL PANEL LAYOUT



828 CONTROL ELECTRICAL PANEL – PARTS

REF	PART NO.	DESCRIPTION	PARTS NAME	QTY
1	SWT-5064	Main Disconnect		1
2	MSE-1912	Fuse Block		1
3		Motor Controller Overloads		1
4		Line Choke		1
5	MSE-2940	24 VDC POWER SUPPLY		1
6	MSE-1410	MC1 Magnetic Contactor		1
7	MSE-1610	Transformer		1
8		Fuse Panel		1
9		Contact Relays		1
10		Combi Drive		1
11		I/O Breakout Board		1
12	MSE-1330	I/O Card		1
13		Terminal Block		1
14		Terminal Block		1

5.2 828 CONTROL PANEL LAYOUT




REF	PART NO.	DESCRIPTION	PARTS NAME	QTY
1	MON-4378	Siemens Monitor NCU		1
2	CMB-3202	Siemens Control Panel		1
3	MSM-8210	Keys (3)		1 set
4	SWT-6210	E-Stop w/ Contact Block		1

5.3 828 3-HANDWHEEL OPERATOR CONSOLE (OPTION)



REF	PART NO.	DESCRIPTION	PARTS NAME	QTY
1	MON-4378	Siemens Monitor NCU		1
2	CMB-3202	Siemens Control Panel		1
3	SWT-6210	E-Stop w/ Contact Block		1
4	70131528	Fine / Course Switch		1
5	ASY-6192	Handwheel (3-Panel)		3
6	MSM-8210	Keys (3)		1 set
7	SWT-5052	Joystick Switch		1


5.3 – Z-AXIS COLUMN ASSEMBLY



FRYER MB-Q PARTS LIST

DRAWING REF. – Z-AXIS COLUMN ASSEMBLY				
ITEM	PART NO.	PART NAME	QTY	SPECIFICATION
1		UPPER COLUMN CASTING	1	
2	NA	SPRING WASHER	6	M10
3	NA	SOCKET HEAD CAP SCREW	6	M10X40
4	NA	FLAT WASHER	6	M10
5	NA	SET SCREW	4	M10X15
6	POL-2360	RADIAL BEARING	4	
7	NA	C CLIP	4	S-25
8		CHAIN SHAFT	4	
9	POL-1012	CHAIN GEAR	4	
10	BEN-1800	CHAIN	2	
11		CHAIN BOLT	4	
12		COUNTERWEIGHT	1	
13	BEN-1802	MASTER LINKS	4	

5.4 – MB-16 HEAD ASSEMBLY




FRYER MB-Q PARTS LIST

DRAWING REF. – MB-16 HEAD ASSEMBLY				
ITEM	PART NO.	PART NAME	QTY	SPECIFICATION
ASSEMBLY A P/N:POL-1938				
4	POL-1940	SPINDLE PULLEY	1	
22		CAP	1	
63		BEARING CASTING	1	
ASSEMBLY B P/N:POL-2078				
25	POL-2080	QUILL HANDLE	1	
33		HUB	1	
94		PIN	1	
ASSEMBLY C P/N:POL-1958				
52	POL-1960	QUILL SPRING MOUNT	1	
102	POL-2020	QUILL SPRING	1	
68		QUILL RACK	1	
3		RACK SUPPORT	1	
66		END CAP	1	
ASSEMBLY D P/N:POL-2310				
88		DETENT PIN	1	
54		SHIFTER KNOB	1	
55		SHIFTER PLATE	1	
16		SHIFTER ROD	1	
46		SHIFTER FORK	1	
6		SHIFTER FORK SHAFT	1	
ASSEMBLY E P/N:POL-2018				
44		QUILL LOCK HANDLE	1	
31	POL-1980	DOG	1	
45		SPRING	1	
30	POL-1980	DOG	1	
ASSEMBLY F P/N:POL-2058				
92		MARKER	1	
34		QUILL STOP BLOCK	1	
17	POL-2060	QUILL STOP NUT	1	
26	POL-2070	NUT LOCK	1	
56	POL-2040	STOP ROD	1	
MISC. ITEMS NOT IN DRAWING				
	POL-1886	COMPLETE HEAD		
	POL-1900	SPINDLE BELT SET	3	
	POL-2010	SPINDLE MOTOR 10HP		
	POL-2172	COOLANT BLOCK		
ITEM	PART NO.	PART NAME	QTY	SPECIFICATION
ASSEMBLY G P/N:POL-1904				
69		SPINDLE	1	

50		SPINDLE LOCK RING	1	
A10	POL-2135	THRUST BEARING	2	
43		OUTER SPACER	1	
47		INNER SPACER	1	
18		SPACER	1	
39		LOCK RING	1	
A9		RADIAL BEARING	1	
71		SPACER	1	
82		LOCK RING	1	
		ASSEMBLY H P/N:POL-1928		
62		RETAINER CAP	1	
36	POL-1930	GEAR	1	
13		RETAINER CAP	1	
A5	POL-2120	RADIAL BEARING	1	
A6	POL-2125	RADIAL BEARING	2	
48		SPACER	1	
29	POL-1934	GEAR	1	
83		SPLINE	1	
A7	POL-2130	RADIAL BEARING	1	
81		SPACER	1	
		ASSEMBLY I P/N:POL-1908		
32		SPACER	1	
A4	POL-2115	RADIAL BEARING	1	
5	POL-1910	MAIN SHAFT	1	
27	POL-1910	CASTLE GEAR	1	
A6	POL-2125	RADIAL BEARING	2	
49		SPACER	1	
70		SPLINE RING	1	
57	POL-2160	DRIVE GEAR	1	
A8		RADIAL BEARING	1	
75		LOWER BEARING CASTING	1	
		MISC. ITEMS		
1		QUILL BOX	1	
100		TILT PINION	1	
74		QUILL STOP COVER	1	
73		BELLOWS	1	
91	POL-1990	SCALE	1	
7	DBR-2020	KURT DRAW BAR	1	
95		COVER	1	
42		QUILL	1	
35	POL-1974	MOTOR PULLEY	1	
A3	POL-2110	RADIAL BEARING	1	
58	POL-1925	UPPER BEARING HOUSING	1	
8		UPPER BEARING RETAINER	1	

5.5 – MB-10/14 LOWER HEAD ASSEMBLY



FRYER MB-Q PARTS LIST

DRAWING REF. – MB-10/14 LOWER HEAD ASSEMBLY

ITEM	PART NO.	PART NAME	QTY	SPECIFICATION
------	----------	-----------	-----	---------------

MISC. PARTS				
142		QUILL	1	
192		QUILL HOUSING	1	

ASSEMBLY "A" P/N:POL-1856				
166		QUILL PINION SHAFT	1	
171	NA	KEY	1	3X3X20
188	POL-1860	QUILL SLEEVE	1	
193		SHAFT BUSHING	1	
194	NA	SNAP RING	1	S15

ASSEMBLY "B" P/N:POL-1840				
186	POL-1840	WORM GEAR	1	
187	NA	KEY	1	4X4X8
189		WORM SHAFT	1	

ASSEMBLY "C" P/N:POL-1322				
172		PINION SHAFT HUB SCREW	1	
176	POL-1322	PINION SHAFT HUB SLEEVE	1	

ASSEMBLY "D" P/N:POL-1330				
175		QUILL FEED HANDLE HUB	1	
190		QUILL FEED HANDLE	1	
191		PLASTIC BALL HANDLE	1	

ASSEMBLY "E" P/N:POL-1818				
177	POL-1820	QUILL SPRING HOUSING	1	
178	POL-1830	QUILL SPRING	1	


ASSEMBLY "F" P/N:POL-1800				
127		SPINDLE	1	
129	NA	SNAP RING	1	S40
130	POL-1790	BEARING	2	
131		BEARING	1	
132	NA	LOCK NUT	1	
133		SPINDLE DIRT SHIELD	1	
134		BEARING SPACER	1	
136		BEARING COLLAR (OUTSIDE)	1	
137		BEARING COLLAR (INSIDE)	1	

ASSEMBLY "G" P/N:POL-1808				
148	POL-1810	QUILL LOCK SLEEVE, REAR	1	
152	POL-1120	QUILL LOCK BOLT	1	
153	POL-1810	QUILL LOCK SLEEVE, FRONT	1	

ASSEMBLY "H" P/N:POL-1302				
----------------------------------	--	--	--	--

160	NA	SNAP RING	1	S 5/8
161	POL-1300	QUILL STOP LOCK NUT	1	
162	POL-1290	QUILL STOP NUT	1	
163	POL-1814	QUILL STOP BLOCK	1	
164	POL-2155	QUILL STOP SHAFT	1	

5.6 – MB-10/14 UPPER HEAD ASSEMBLY



FRYER MB-Q PARTS LIST

DRAWING REF. – MB-10/14 UPPER HEAD ASSEMBLY

ITEM	PART NO.	PART NAME	QTY	SPECIFICATION
		MISC. PARTS		
1	POL-1530	BELT HOUSING	1	
11	POL-1610	BELT HOUSING BOTTOM COVER	1	
13	POL-1620	TOP BEARING HOUSING	1	
15	POL-1630	BEARING	1	
101		SIDE PLATE	2	
104		FRONT PLATE	1	
3	POL-2010	SPINDLE MOTOR	1	10 HP
197	BEN-1085	MAIN SPINDLE BELT		
63	POL-1730	BACK GEAR BELT		ROUND TOOTH

ASSEMBLY "J" P/N:POL-1698				
61	NA	NUT	1	5/8 NF
62	POL-1710	BACK GEAR PULLEY	1	57T
64	POL-2188	BACK GEAR PINION BEARING CAP	1	
65	POL-1740	BEARING	2	
66		BACK GEAR PINION	1	
67	POL-1750	BACK GEAR PINION COUNTER SHAFT	1	
68	NA	KEY	1	5X5X15
69	NA	KEY	1	5X5X18
93	NA	WASHER	1	SW-5/8

ASSEMBLY "P" P/N:POL-1778				
20	NA	CLUTCH COLLAR	1	
26	NA	KEY	1	8X7X24
30		SET RING	1	
45		BOTTOM VARIDISK (SPINDLE SIDE)	1	
43	POL-1656	BEARING	1	
50		BRAKE HOUSING	1	
70	POL-1780	BRAKE HOUSING CENTER SHAFT	1	
83	NA	SET NUT	1	M97
97	NA	SNAP RING	1	S50
196		SPINDLE PULLEY	1	


ITEM	PART NO.	PART NAME	QTY	SPECIFICATION
ASSEMBLY "Q" P/N:POL-1796				
32	NA	SUN WASHER	1	50
72	NA	KEY	1	8X7X12
73		SPINDLE GEAR HUB	1	
74	POL-2290	SPINDLE BULL GEAR	1	
75	POL-2290	BEARING SLEEVE	1	
76		SPRING PLATE	1	
77	POL-1760	BEARING	2	
78		BEARING SPACER (INSIDE)	1	
79		BEARING SPACER (OUTSIDE)	1	
80	NA	SNAP RING	1	R72
81	NA	SET NUT	1	M50
96	NA	PAD	1	

ASSEMBLY "R" P/N:POL-1280				
57		PLASTIC GRIP	1	
87		BULL GEAR SHAFT	1	
89		HI-LOW DETENT BLOCK	1	
90		DETENT PIN	1	
91		SPRING	1	
92		HI-LOW PINION BLOCK	1	
94		HI-LOW SHIFTER	1	

ASSEMBLY "S" P/N:POL-1784				
82		GEAR HOUSING	1	
85		STUD	4	7/16 NC

MISC. ITEMS NOT IN DRAWING				
	DBR-2040	KURT POWER HEAD	1	
	DBR-2090	KURT IN/OUT CONTROL	1	
	DBR-2094	KURT AIR REGULATOR	1	

5.7 – Z-AXIS BALL SCREW ASSEMBLY




FRYER MB-Q PARTS LIST

DRAWING REF. – Z-AXIS BALL SCREW ASSEMBLY				
ITEM	PART NO.	PART NAME	QTY	SPECIFICATION
1	NA	SOCKET HEAD CAP SCREW	3	M6X15
2		BEARING COLLAR	1	
3	NA	LOCK NUT	1	AN-05
4	NA	SUN WASHER	1	AW-05
5		PULLEY (BALLSCREW SIDE)	1	
6		BEARING COLLAR	1	
7	POL-1040	THRUST BEARING	1SET	
8	NA	SOCKET HEAD CAP SCREW	4	M10X30
9	POL-1242	BEARING CUP	1	
10	NA	KEY	1	6X6X27
11	NA	SOCKET HEAD CAP SCREW	4	M6X15
12	POL-1240	BALL SCREW MB 10-14	1	
	POL-1370	BALL SCREW MB16		
13		YOKE	1	
14	NA	SOCKET HEAD CAP SCREW	4	M10X30
15		BEARING CUP	1	
16	NA	SOCKET HEAD CAP SCREW	4	M10X35
17		BEARING COLLAR	1	
18	POL-2140	RADIAL BEARING	1	
19		BEARING COLLAR	1	
20	POL-1244	BEARING COLLAR		
21	NA	SOCKET HEAD CAP SCREW	3	M6X20
22	POL-1018	MOTOR BELT	1	
23		MOTOR PULLEY	1	

MISC. ITEMS NOT IN DRAWING				
	POL-1010	WORK LAMP		
	POL-1000	WORK LAMP BULB		


5.8 – X-AXIS TABLE ASSEMBLY



FRYER MB-Q PARTS LIST

DRAWING REF. – X-AXIS TABLE ASSEMBLY				
ITEM	PART NO.	PART NAME	QTY	SPECIFICATION
1		TABLE	1	
2	POL-1250	WIPER SET MB10-14	4	
	POL-1440	WIPER SET MB16		
3	NA	FLAT WASHER	8	M5
4	NA	BUTTON HEAD SCREW	8	M5X10
5	POL-1170	WAYCOVER LEFT MB10-14	2	
	POL-1160	WAYCOVER RIGHT MB10-14		
	POL-1390	WAYCOVER LEFT MB16		
	POL-1380	WAYCOVER RIGHT MB16		
6	NA	FLAT WASHER	8	M8
7	NA	SPRING WASHER	8	M8
8	NA	SOCKET HEAD CAP SCREW	8	M8X25
9		GIB	2	
10	NA	HEX NUT	5	M8
11	NA	SOCKET HEAD CAP SCREW	2	M8X80
12		FIXED PLATE	2	
13	NA	SET SCREW	2	M8X80


5.9 X-AXIS BALL SCREW ASSEMBLY



FRYER MB-Q PARTS LIST

DRAWING REF. – X-AXIS BALL SCREW ASSEMBLY				
ITEM	PART NO.	PART NAME	QTY	SPECIFICATION
1	NA	SOCKET HEAD CAP SCREW	4	M8X65
2		X AXIS MOTOR BELT COVER	1	
3	NA	SOCKET HEAD CAP SCREW	3	M6X15
4		THRUST BEARING COLLAR	2	
5	NA	LOCK NUT	2	AN-05
6	NA	SUN WASHER	2	AW-05
7	POL-1052	DRIVE PULLEY (BALL SCREW SIDE)	1	
8		BEARING COLLAR	1	
9	POL-1040	THRUST BEARING	1 SET	
10	NA	SOCKET HEAD CAP SCREW	4	M10X30
11	POL-1064	X AXIS MOTOR BRACKET	1	
12	NA	KEY	1	6X6X27
13	NA	SOCKET HEAD CAP SCREW	4	M6X15
14	POL-1220	X AXIS BALL SCREW MB10-14	1	
	POL-1470	X AXIS BALL SCREW MB16		
15		X AXIS YOKE	1	
16	NA	SOCKET HEAD CAP SCREW	4	M10X30
17		RADIAL BEARING HOUSING	1	
18	NA	SOCKET HEAD CAP SCREW	4	M8X15
19		BEARING COLLAR	1	
20	POL-2140	RADIAL BEARING	1	
21		RADIAL BEARING COLLAR	1	
22	NA	SOCKET HEAD CAP SCREW	3	M6X15
23	POL-2150	BEVEL GEAR	2	
24	NA	SET SCREW	2	M6X10
25	NA	C CLIP	2	S-20
26	POL-1270	RADIAL BEARING	2	
27		BEARING SEAT	1	
28	NA	SOCKET HEAD CAP SCREW	3	M10X45
29		CENTRAL SHAFT	1	
30	NA	KEY	2	6X6X15
31		INDICATING DIAL	1	
32	NA	SOCKET HEAD CAP SCREW	3	M6X15
33		DIAL	1	
34		TOOTH CLUTCH	1	
35	NA	C CLIP	1	S-16
36	HDL-6010	HAND WHEEL		
36	POL-1018	AXIS BELT	1	
37	POL-1016	MOTOR PULLEY	1	


5.10 – Y-AXIS SADDLE ASSEMBLY



FRYER MB-Q PARTS LIST

DRAWING REF. – Y-AXIS SADDLE ASSEMBLY				
ITEM	PART NO.	PART NAME	QTY	SPECIFICATION
1		SADDLE	1	
2	NA	SUPPORT (LEFT)	1	
3	NA	SOCKET HEAD CAP SCREW	8	M12X35
4		LOCK SCREW	6	
5		GIB	2	
6		GIB (MIDDLE)	1	
7	POL-1260	WIPER (FRONT LEFT) SET MB 10-14	1	
	POL-1450	WIPER SET MB16		
8	NA	FLAT WASHER	16	M5
9	NA	BUTTON HEAD SCREW	16	M5X10
10	NA	SUPPORT (RIGHT)	1	
11	POL-1260	WIPER (FRONT RIGHT) MB10-14	1	
12	POL-1260	WIPER (REAR RIGHT) MB10-14	1	
13	POL-1260	WIPER (REAR RIGHT) MB10-14	1	
	POL-1180	FRONT WAYCOVER MB 10-14		
	POL-1190	REAR WAYCOVER MB 10-14		
	POL-1410	FRONT WAYCOVER MB16		
	POL-1400	REAR WAYCOVER MB16		

5.11 – Y-AXIS BALL SCREW ASSEMBLY




FRYER MB-Q PARTS LIST

DRAWING REF. – Y-AXIS BALL SCREW ASSEMBLY				
ITEM	PART NO.	PART NAME	QTY	SPECIFICATION
1	HDL-6010	HAND WHEEL	1	
2	NA	C CLIP	1	S-16
3		TOOTH CLUTCH	1	
4		DIAL	1	
5		INDICATING DIAL	1	
6	NA	SOCKET HEAD CAP SCREW	1	
7		MOTOR COVER	1	
8	NA	SOCKET HEAD CAP SCREW	4	M8X65
9	NA	SOCKET HEAD CAP SCREW	3	M6X15
10		BEARING COLLAR	1	
11	NA	LOCK NUT	2	AN-05
12	NA	SUN WASHER	2	AW-05
13	POL-1052	PULLEY (BALL SCREW SIDE)	1	
14	POL-1276	BEARING COLLAR	1	
15	NA	SOCKET HEAD CAP SCREW	4	M10X30
16	POL-1040	THRUST BEARING	1SET	
17		BEARING CUP	1	
18	NA	KEY	1	6X6X15
19	NA	KEY	1	6X6X27
20	NA	SOCKET HEAD CAP SCREW	4	M6X15
21	POL-1230	Y AXIS BALL SCREW MB10-14	1	
	POL-1360	Y AXIS BALL SCREW MB16		
22		YOKE	1	
23	NA	SOCKET HEAD CAP SCREW	4	M10X30
24		BEARING CUP	1	
25	NA	SOCKET HEAD CAP SCREW	4	M10X35
26		BEARING COLLAR	1	
27	POL-2140	RADIAL BEARING	1	
28		BEARING COLLAR	1	
	POL-1018	MOTOR BELT	1	

MISC. ITEMS NOT IN DRAWING				
	POL-1110	FLOOD PUMP		OPTION
	POL-1070	WAY OILIER		

5.12 – Z-AXIS RAM ASSEMBLY



FRYER MB-Q PARTS LIST

DRAWING REF. – Z-AXIS RAM ASSEMBLY				
ITEM	PART NO.	PART NAME	QTY	SPECIFICATION
1		RAM	1	
2		GIB	1	
3		HOLDER (MIDDLE)	1	
4	NA	SOCKET HEAD CAP SCREW	8	M12X35
5		HOLDER (RIGHT)	1	
6		GIB	2	
7	NA	LOCK SCREW	6	
8	POL-1270	WIPER (UPPER LEFT) MB10-14	1	
	POL-1460	WIPER SET MB16		
9	NA	FLAT WASHER	12	M5
10	NA	BUTTON HEAD SCREW	12	M5X10
11	POL-1270	WIPER (UPPER RIGHT) MB10-14	1	
12	POL-1270	WIPER (LOWER LEFT) MB10-14	1	
13	POL-1270	WIPER (LOWER RIGHT) MB10-14	1	
	POL-1200	LOWER WAYCOVER MB10-14		
	POL-1210	UPPER WAYCOVER MB10-14		
	POL-1420	UPPER WAYCOVER MB16		
	POL-1430	LOWER WAYCOVER MB16		